

Table of contents

Table of contents	1
Chapter 1 Product Information	3
1.1 About servo driver	3
1.2 About servo motor	12
1.3 List of servo unit and servo motor combinations	23
Chapter 2 Installation Instruction	24
2.1 Installation of servo driver	24
2.2 Installation of servo motor	26
Chapter 3 Peripheral Devices and Wiring	29
3.1 Diagram for wiring of peripheral devices	29
3.2 Selection of cable and peripheral accessories	32
3.3 Wiring of connector CN1	37
3.4 Wiring of connector CN2	46
3.5 Wiring of connector CN3	46
3.6 Wiring of connector CN4	47
3.7 Wiring of connector CN5	50
3.8 Wiring of connector on motor side	51
Chapter 4 Display and Operation of Panels	52
4.1 Introduction to keys on panel	52
4.2 Change of operation mode	53
4.3 Setting of parameters for group P	54
4.4 Display of parameter for group U	54
4.5 Description on use of parameter of group F	55
4.6 Fault display	56
Chapter 5 Control and Timing Sequence	57
5.1 Diagram for timing sequence of powering on	57
5.2 Diagram for timing sequence of brake enable	58
5.3 Diagram for timing sequence of shutdown	60
5.4 Release Function Setting	62
Chapter 6 Control Mode	63
6.1 Position Control Pulse Mode	63
6.2 Position control homing mode	69
6.3 Speed mode	85
6.4 Torque mode	89
6.5 Mode switch	92
Chapter 7 Adjustment	93
7.1 Gain adjustment target	93
7.2 Manual gain adjustment	95
Chapter 8 Communication Mechanism	117
8.1 Mod bus communication protocol	118
8.2 RTU function command	119
8.3 Mod bus function code communication address	121
Chapter 9 Alarm Treatment	122
Chapter 10 List of Function Code	129
10.1 List of parameter	129


10.2 DI/DO function	159
Chapter 11 Commissioning of Linear Motor	160
11.1 Procedure for commissioning of linear motor	160
11.2 Parameter setting of linear motor.....	160
11.3 Check the signal feedback of linear motor	163
11.4 Linear angle identification.....	164
11.5 Linear commissioning	165

Chapter 1 Product Information

1.1 About servo driver


Description on driver model

TDS – R1 – P A 2R8 – B00




Note: A driver model with A00 or a default suffix is a standard unit.

Description on driver nameplate



Composition of servo driver



Specifications for servo driver

Electrical specification

Item	Type SIZE-A				Type SIZE-B		
	R70	R90	1R6	2R8	3R8	5R5	7R6
Driver model TDS-R*-PA**	R70	R90	1R6	2R8	3R8	5R5	7R6
Continuous output current (A)	0.7	0.9	1.6	2.8	3.8	5.5	7.6
Maximum output current(A)	2.1	3.2	5.9	9.3	11	16.9	17
Voltage specification of input power supply	Single-phase AC200V-240V , +10~-15% , 50/60HZ						
Current specification of input power supply (A)	0.8	1.6	2.4	5	6.3	8.7	10
Brake handling function	External brake resistance				Built-in brake resistance		
Resistance value of built-in braking resistance(Ω)	—	—	—	—	50	50	50
Capacity of built-in brake resistor(W)	—	—	—	—	50	50	50
Minimum resistance value of external braking resistance(Ω)	40	40	40	40	40	40	40

Basic specifications

Item		Descriptions	
Basic specifications	Control mode		IGBT PWM control, sine wave current driver mode.
	Encoder feedback	Rotary motor	R0 Series: Incremental line saving Encoder:2500 line incremental encoder R1 Series: Bus type serial encoder: 17bit (absolute/incremental encoder) 23bit (absolute/incremental encoder)
		Linear motor	Absolute linear encoder (signal resolution varies with absolute linear encoder) Incremental linear encoder (signal resolution varies with incremental linear encoder and serial conversion unit)
	Control signal	Digital input signal	General 8 input General input function is selected by parameters
		Digital output signal	General 5 output General output function is selected by parameters
	Analog signal	Input	1 channel of 12bit A/D input
	Communication function	USB	Connect with computer, etc
		RS485	Possible for 1: n communication with maximum 247 shaft
		Axes address setting	Based on user settings
	Dynamic brake		Built-in

Item		Descriptions	
	Control model	Velocity mode, torque mode, position mode, position/velocity mode, position/torque mode, velocity-torque mode, full closed loop mode The above 7 control modes can be switched by parameters	
Performance	Velocity variation rate *1	Load variation rate	Less than $\pm 0.1\%$ of rated velocity (load fluctuation: 0~100%)
		Voltage variation rate	0% of rated velocity (voltage fluctuation: $\pm 10\%$)
		Temperature variation rate	Less than 0.1% of rated velocity (temperature fluctuation: $25 \pm 25^{\circ}\text{C}$)
	Velocity control range		1:6000
	Frequency characteristics of velocity loop		3.0KHZ
	Torque control accuracy		$\pm 1\%$
	Velocity control mode	Soft start time setting	
Control input		Change to enable switch, over-travel switch, command disable switch, internal mode selector switch, internal command selector switch, etc.	
Control output		Servo ready, positioning OK brake output, velocity reach, torque reach, etc	
Analog command input		Command voltage	Maximum input voltage: $\pm 12\text{V}$ maximum (motor rotates positive in case of a positive voltage command) The rotating velocity at DC10V is 3000rpm(*mm/s), and the corresponding rotating velocity can be set as required.

Item		Descriptions	
	Analog command input	Input impedance	Appr 9kΩ
		Circuit time parameters	Appr 47μs
Torque control mode	Analog command input	Command voltage	Maximum input voltage: ± 12V maximum (net torque output of motor in case of a positive voltage command) The torque is 100% at dc10v, and the corresponding torque can be set freely
		Input impedance	Appr 9kΩ
		Circuit time parameters	Appr 47μs
Position control mode	Filtering setting		Smooth filtering, low-pass filtering, low-frequency jittering-suppression and other command processing
	Feed-positive compensation		0 ~ 100.0%
	Output signal positioning width setting OK		Command unit and encoder unit are settable, in an unit of 1
	Input signal	Impulse command	Input pulse shape
Input shape			Differential input, open-circuited collector

Item		Descriptions	
Position control mode	Input signal		Differential input: 4mpps maximum, pulse width no less than 0.125us; open-circuited collector : 200kpps maximum , pulse width no less than 2.5us.
		Electronic gear ratio	$\frac{\text{Encoding resolution}}{10^8}$ $\leq \frac{\text{Electronic gear ratio numertor}}{\text{Electronic gear ratio denominator}}$ $\leq \frac{\text{Encoding resolution}}{2.5}$
		Power supply for built-in collector in case of open circuit * 2	+24V(built in 2.4kΩ resistor)
	Encoder frequency division pulse output	Clear signal	Position deviation clearing, supports linear drive and open-circuited collector
		Output shape	Phase A, phase B: differential output Phase Z: Differential output or open-circuited collector output
		Frequency division ratio	Any frequency division

Item		Descriptions	
I/O signal	Digital input signal	Possible to make change in signal distribution	8-channel DI DI function: Servo enable, alarm reset, gain switch, zero position fixing function enable, position command disable, positive over-travel switch, negative over-travel switch, positive jogging, negative jogging, electronic gear selection, home switch, home reset enable, position deviation clearing, internal velocity limit selection, and pulse command disable.
	Digital output signal	Possible to make change in signal distribution	5-channel DO DO function: Servo ready, motor rotating, zero-velocity signal, velocity consistent, positioning OK, torque limit, velocity limit, brake output, warning output, fault output, home reset OK, torque reach, and velocity reach.
Built-in function	Over-travel (OT) prevention function		Stop immediately when P-OT and N-OT are triggered.
	Protection function		Overcurrent, overvoltage, insufficient voltage, overload, main circuit detection abnormality, radiator overheating, power supply phase failure, overvelocity, encoder abnormality, CPU abnormality, parameter abnormality, and others
	LED display function		Main power supply CHARGE, 5-bit LED display

Item	Descriptions
Analog quantity monitoring function for observation	Provided with built-in analog quantity monitoring connector for observing velocity, torque command signal, etc
Vibration suppression	Compatible with 0-100Hz low frequency suppression Compatible with 100-5000Hz medium-high frequency suppression
Others	Gain adjustment, alarm recording, IOG operation

Note *1: The velocity variation rate is defined by the following formula:


$$\text{Velocity variation rate} = \frac{\text{Noload velocity} - \text{Fullload velocity}}{\text{Rated velocity}} * 100\%$$

In fact, the variation of voltage and temperature will lead to the deviation of amplifier and the variation of hydrochloric acid resistance. Therefore, such variation will be shown by the variation of the rotational velocity. The variation rotational velocity is expressed by the ratio of the rated rotational velocity, which is the rate of variation of velocity caused by voltage variation and temperature variation respectively.


Note * 2: The power supply for the open-circuited built-in collector is not electrically isolated from the control circuit in the servo driver.

Installation dimension of servo driver

SIZE-A installation dimension diagram (in: mm) :



SIZE-B installation dimension diagram (in: mm) :



1.2 About servo motor

Description on model of EAM-S/T series servo motor

EAM – S F-0430A-U 3 0 – X X

Mark	Serial No.
EAM	Servo motor

Mark	Motor series
S	S series
T	T series
...	...

Mark	Motor series
F	Low inertia
G	Middle inertia
H	High inertia

Mark	Rated power (W)
A5	50
01	100
02	200
04	400
06	600
08	750
09	850
10	1000
13	1300
15	1500
18	1800
20	2000
25	2500
29	2900
30	3000

Mark	Rated velocity (rpm)
15	1500
20	2000
25	2500
30	3000

Mark	Voltage grade
A	AC 200V
T	AC 400V
D	DC 48V

Mark	Customer code
01	1# non-standard

Mark	Brake, reducer, oil seal
0	Oil seal
1	No oil seal
2	Oil seal + brake
4	Brake


Mark	Shaft connection mode
1	Optic shaft
2	Solid, keyed
3	Solid, keyed, with threaded hole
4	Solid, with threaded hole

Mark	Encoder type
1	2500-wire line-saving incremental encoder
2	S-type 17-bit multi-ring absolute value encoder
3	S-type 17-bit single-ring absolute value encoder
4	R-type 17-bit multi-ring absolute value encoder
5	R-type 17-bit single-ring absolute value encoder
6	1024-wire line-saving incremental encoder
D	20-bit bus encoder
U	23-bit multi-ring absolute value encoderbus encoder

Note: A servo motor model with a default suffix is a standard unit.

1.2.1 Description on EAM-S series servo motor

Description on nameplate of EAM-S series servo motor



Specification for mechanical characteristic parameters of EAM-S series servo motor

Item	Description
Rated time	Continuous
Vibration level	V15
Insulation	DC500V , 10MΩand above
Operating	0 ~ 40℃
Excitation mode	Permanent magnet type
Installation mode	Flange type
Heat resistance	Level F
Isolation voltage	AC1500V 1min(200V level)
Housing	IP65
Operating	20 ~ 80%(no condensation)
Connection mode	Direct connection
Rotation direction	Counter clockwise (CC rotation) when viewed from load side

Specification for rating of EAM-S series servo motor

Model	Base output	Rated	Rated	Max	Rated	Max	Rated	Max	Torque	Rotor	Voltage
	(kW)*1	(N m)	(N m)	(A)	(A)	(rpm)	(rpm)	(N m/A)	(10-4kg m ²)	(V)	
EAM-SF-0130A-***	40	0.1	0.32	0.96	0.8	2.4	3000	5000	0.4	0.035	220V
EAM-SF-0230A-***	60	0.2	0.64	1.92	1.1	3.3			0.58	0.264	
EAM-SF-0430A-***		0.4	1.27	3.81	2.3	6.9			0.55	0.407	
EAM-SF-0630A-***		0.6	1.91	5.7	3.8	11.4			0.5	0.526	
EAM-SF-0830A-***		80	0.75	2.39	7.2	4.2			12.6	0.6	
EAM-SF-1030A-***	1.0		3.18	9.6	4.5	13.5			0.71	1.207	
EAM-SF-1230A-***	110	1.2	4	12	4.5	15	3500	0.89	7.62		
EAM-SF-1530A-***		1.5	5	15	5.5	18		0.91	9.45		
EAM-SF-1830A-***		1.8	6	18	7	18		0.85	11.3		


Note: Please communicate with our technicians when selecting motor with base 110.

Electrical specification for brake of EAM-S series brake motor					
Motor model	Power supply voltage(V) ±10%	Out of time	In time (ms)	Rated power (w)	Brake holding torque (N.m)
EAM-SF-A530A /0130A	DC24	20	50	6.1	≥0.32
EAM-SF-0230A/0430A/0630A		40	50	6.44	≥1.32
EAM-SF-0830A/1030A		40	60	11.5	≥3.2
EAM-SF-1230A/1530A/1830A		60	120	14.4	≥6


- ▶ The brake shall not share power supply with other electrical appliances to prevent the voltage or current from decreasing due to the operation of other electrical appliances, which will eventually cause the brake to malfunction.
- ▶ Cables with a specification of more than 0.5mm^2 will be recommend

Installation dimensions of EAM-S series servo motor


Installation dimension diagram for 100W servo motor without brake (in: mm):




Installation dimension diagram for 100W servo motor with brake (in: mm):




Installation dimension diagram for 200W servo motor without brake (in: mm):




Installation dimension diagram for 200W servo motor with brake (in: mm):




Installation dimension diagram for 400W servo motor without brake (in: mm):




Installation dimension diagram for 400W servo motor with brake (in: mm):




Installation dimension diagram for 600W servo motor without brake (in: mm):




Installation dimension diagram for 600W servo motor with brake (in: mm):




Installation dimension diagram for 750W servo motor without brake (in: mm):




Installation dimension diagram for 750W servo motor without brake (in: mm):



Installation dimension diagram for 1000W servo motor without brake (in: mm):




Installation dimension diagram for 1000W servo motor with brake (in: mm):



1.2.2 Description on EAM-T series motor

Description on nameplate of EAM-T series motor

Motor nameplate	AC SERVO MOTOR		
Motor model	Model:EAM-TH-0430A-530		
Motor parameter	Input 3φAC220V 3.2A	IP65	
	Output 0.4kW	Torque 1.27N.m	
	Rated REV.3000rpm	Ins.F	
S/N No.	SN: 620207519100001		

Specification for mechanical characteristic parameters of motor

Item	Description
Rated time	Continuous
Vibration level	V15
Insulation resistance	DC500V , 10MΩand above
Operating ambient	0 ~ 40℃
Excitation mode	Permanent magnet type
Installation mode	Flange type
Heat resisting class	F level
Isolation voltage	AC1500V 1min(200V level)
Housing protection mode	IP65
Operating ambient	20 ~ 80%(No condensation)
Connection mode	Direct connection
Rotation direction	Counter clockwiserotation (CCW) when viewed from load side under positive rotation command

Specification for rating of EAM-T series servo motor

Model	Base	Rated output (kW)*1	Rated torque (N.m)	Max torque (N.m)	Rated current (A)	Max current (A)	Rated velocity (rpm)	Max velocity (rpm)	Torque parameter (N.m/A)	Rotor inertia (10-4kg.m ²)	Voltage (V)
EAM-TH-0130A-53*	40	0.1	0.32	0.96	1.1	3.3	3000	6000	0.306	0.048 (0.051)	220
EAM-TH-0230A-53*		0.2	0.64	2.23	1.9	6.6		6500	0.33	0.29 (0.31)	
EAM-TH-0430A-53*		0.4	1.27	4.46	3.2	11.2		6500	0.4	0.56 (0.58)	
EAM-TH-0830A-53*		0.75	2.39	8.36	5.1	17.8		6500	0.465	1.56 (1.66)	


Note: The data in brackets refer to relevant parameters of the brake motor.

Electrical specification for brake of EAM-T series brake motor:


Motor model	Power supply voltage (V) $\pm 10\%$	Disengaging time (ms)	Engaging time (ms)	Rated power (W)	Brake holding torque (N.m)
EAM-TF-0130A-532	DC24	20	60	6.1	≥ 0.32
EAM-TH-0230A/0430A-532		20	60	7.6	≥ 1.5
EAM-TH-0830A-532		20	60	8.5	≥ 2.5

Installation dimension of EAM-T series servo motor


EAM-TF-0130A-530 Installation dimension diagram for 100W servo motor without brake




EAM-TF-0130A-532 Installation dimension diagram for 100W servo motor with brake




EAM-TH-0230A-530 Installation dimension diagram for 200W servo motor without brake:




EAM-TH-0230A-532 Installation dimension diagram for 200W servo motor with brake:




EAM-TH-0430A-530 Installation dimension diagram for 400W servo motor without brake




EAM-TH-0430A-532 Installation dimension diagram for 400W servo motor with brake



EAM-TH-0830A-530 Installation dimension diagram for 750W servo motor without brake (in mm):



EAM-TH-0830A-532 Installation dimension diagram for 750W servo motor without brake :



1.3 List of servo unit and servo motor combinations

Servo motor model		Power	Servo driver model	
EAM-SF EAM-TF EAM-TH	EAM-SF-A530A	50W	TDS-R*	TDS-R*-PAR70
	EAM-SF-0130A	100W		TDS-R*-PAR90
	EAM-SF-0230A	200W		TDS-R*-PA1R6
	EAM-SF-0430A	400W		TDS-R*-PA2R8
	EAM-SF-0630A	600W		TDS-R*-PA3R8
	EAM-SF-0830A	750W		TDS-R*-PA5R5
	EAM-SF-1030A	1000W		TDS-R*-PA5R5
	EAM-SF-1230A	1200W		TDS-R*-PA7R6
	EAM-SF-1530A	1500W		TDS-R*-PA7R6
	EAM-SF-1830A	1800W		TDS-R*-PA7R6

Note: Please communicate with our technicians when selecting a motor with base 110.

Chapter 2 Installation Instruction

2.1 Installation of servo driver

Installation site

- ▶ Install this product in a control panel within a room free from rain and direct sunlight, and without flammable materials placed around, as it is provided with no waterproof structure.
- ▶ Do not use this product in an environment with corrosive gas or liquid.
- ▶ Do not use this product in an environment with flammable gas or near combustible materials.
- ▶ Do not install this product in a place with high temperature, humidity, dust, cutting fluid, oil mist, metal dust, etc..
- ▶ Install this product in a well ventilated, dry and dust-free place.
- ▶ Install this product in a vibration-free place.
- ▶ Do not use gasoline, diluents, alcohol, acid and alkaline cleaning agent to avoid discoloration or damage of the housing.

Environmental conditions

Item	Conditions
Altitude	The altitude shall be less than 1000m, in case of an altitude of 1000m and above, the product should be derated in use (to be de-rated by 10% for every 500m increase in altitude)
Atmospheric	86kPa~106kPa
Operating temperature	0 ~ +55℃ (in case of an ambient temperature of 40-55℃, the average load rate should not exceed 80%) (no condensation * 2)
Save	-20~85℃ (no condensation*2)
Humidity	Less than 90%RH (no condensatio*2)
Vibration	Less than 10~60HZ 5.88 m/s ² (0.6G) , less than 20Hz 9.80665 m/s ² (1G)
Impact	19.6m/s ²
IP grade	IP20
Pollution level	PD2


*1 Allowable temperature for a short time including transportation factors.

*2 Please note that condensation is easy to occur when the temperature decreases and the humidity increases.

Installation and precaution

Installation direction

- ▶ This product is provided with a vertical structure; please ensure that the drive is installed vertically.
- ▶ The driver shall be firmly fixed on the mounting surface through the mounting hole as shown in the diagram (by M4 mounting screws, with a recommended torque of 1.7~2N·m).



Cooling


- ▶ Please leave enough space around the driver for effective cooling, with a spacing more than 50mm to be preserved above and below the driver, as shown in the above figure, and a lateral spacing of more than 10mm to be maintained in case of multiple drives installed side by side.
- ▶ Using the driver in the sealed control box will cause the temperature in the control box to rise abnormally. In order to meet the requirements for the operating temperature range around the driver, please consider configuring a cooling device.

Grounding

- ▶ Be sure to ground the ground terminal. If the grounding is not sufficient, the driver will not only be unable to give full play to its own functions, but also may cause safety problems such as wrong actions due to electric shock or interference.
- ▶ When there is a coating on the installation part of the cabinet body corresponding to the driver, please scrape off the coating before installation, which will help prevent noise.

Wiring

- ▶ Please confirm the correct wiring. Improper or wrong wiring will cause the motor to lose control or burn out. In addition, do not let conductive objects such as wire scraps fall into the driver during installation and wiring operations.
- ▶ When the wire is bundled and inserted into the metal tube for use, the allowable current of the wire will decrease due to temperature rise, thus causing burns. Please confirm the current reduction factor before selecting wires.
- ▶ When using stranded wires, please use insulated rod terminals or insulated round terminals to tidy up the wires. If used in an uncluttered state, unexpected accidents or injuries such as electric shock or leakage may occur.
- ▶ When wiring the driver, please set the cable downward (as shown in the right figure) to prevent liquid from flowing into the driver along the cable, which may cause damage to the driver.



Others

- ▶ Do not apply vibration or impact (more than 5.88 m/s^2) to the product, do not place the product in a place where dust, metal scraps, oil mist and other foreign matters accumulate, do not place the product in liquids such as water, oil, cutting fluid, etc., do not allow the product to get close to combustible materials or corrosive gasoline (H_2S , SO_2 , NO_2 , Cl_2 , etc.), and avoid storing or using the product in flammable gas and other similar environments.
- ▶ The power supply for molded case circuit breaker (MCCB) must be set. In addition, the ground wire terminal or ground wire must be grounded.
- ▶ Due to possible wrong actions when turning on the power supply, please do not approach the motor and the machine driven by the driver.
- ▶ When running at high velocity, please set a stop time of about 10min when the dynamic brake is activated.
- ▶ Please make sure that the terminal brake screw and the ground wire screw have been fully tightened.

2.2 Installation of servo motor

Installation site

- ▶ Please install the motor in a site that meets the following conditions as its service life will depend on the quality of the installation site.
- ▶ Install this motor within a room free from rain and direct sunlight.
- ▶ Do not use this product in an environment with corrosive gas or liquid.
- ▶ Do not use this product in an environment with flammable gas or near combustible materials.
- ▶ Do not install this product in a place with high temperature, humidity, dust, cutting fluid, oil mist, metal dust, etc.
- ▶ Please install this product in a place with good ventilation, free from moisture, oil or water intrusion, and away from heat sources.
- ▶ Please install this product in a place convenient for inspection and cleaning.
- ▶ Please install this product in a vibration-free place.

Environmental condition

Item	Conditions
Altitude	The altitude shall be less than 1000m, in case of an altitude of 1000m and above, the product should be derated in use
Temperature	0°C~40°C (No condensation)
Save temperature	-20°C~60°C (Maximum temperature guarantee: no condensation at 80°C for 72 hours)
Humidity	Less than 90% RH (no condensation)
Vibration	Less than 49m/s ² (5G) when rotating, less than 24.5m/s ² (2.5G) when stopping
Impact	Less than 98m/s ² (10G)
IP grade	IP67(The through part of the axes, except the connecting terminal part of the motor connectorr)

* 1 Ambient temperature refers to the temperature 5cm from the motor.

* 2 Allowable temperature for a short time including transportation factors.

Installation precaution

Installation direction


It is acceptable to install the motor vertically or horizontally, subject to the following requirements.

① Horizontal installation

Turn the cable outlet downward to prevent oil and water from penetrating into the motor.

② Vertical installation

When a motor with reducer is installed axially, please use a motor with oil seal to prevent the reducer oil from penetrating into the motor.




Mechanical coupling

▶ When installing or removing the coupling at the shaft end of the motor, do not directly strike the shaft end with a hammer (If installed at the shaft end on the negative load side, the encoder will be damaged).

▶ Sufficient coaxiality shall be required (otherwise vibration or damage to bearings and encoders may occur).

▶ When the motor shaft is running without grounding, depending on the condition of the motor and the installation environment, electrical corrosion

and excessive bearing sound may occur on the motor bearing, which should be confirmed and checked.



Oil and water protection

- ▶ Do not use cables in oil or water.
- ▶ Please set the cable outlet downward.
- ▶ Do not use in an environment where oil and water often splash down on the motor body.
- ▶ When used in combination with reducer, please use a motor with oil seal to prevent oil from penetrating into the motor from the extension of the shaft.

Stress of cable


- ▶ Do not stress the outgoing and connecting part of the cable due to bending and self weight.
- ▶ Especially when moving the motor, use the trunk cable which can be stored in the cable tray. Minimize the bending stress of the cable.
- ▶ Increase the bending radius of the cable as much as possible, and make sure it is more than 10 times of the cable processing outer diameter.

Connection


- ▶ During installation and wiring operation, do not let conductive objects such as wire chips fall into the connector.
- ▶ During wiring, make sure that the connector pins are correctly arranged.
- ▶ Please fully avoid the stress applied to the connector due to the bending of the cable, which may cause damage to the connector.
- ▶ Please make sure that the grounding of the motor is reliably connected with the driver to prevent noise or wrong action due to electric shock or other safety issues.

Chapter 3 Peripheral Devices and Wiring

3.1 Diagram for wiring of peripheral devices




Description on system wiring and key points




Key points of wiring:

- ▶ Wiring operations shall be carried out by electrical engineering experts.
- ▶ Do not switch on the power supply before the wiring operation is finished, so as to avoid electric shock accidents.
- ▶ Please note that connector CN5 has high voltage to avoid electric shock.
- ▶ Please make sure the connector is inserted until a sound indicating that it get locked.

In order to ensure a good EMC environment, be sure to use a single point grounding mode as shown in the figure





3.2 Selection of cable and peripheral accessories

List of cable supporting driver and motor

Model of Servo Motor	Name	Type	Long(L)	Order type
EAM-SF/TF/TH-A5,01,02,04,06,08,10 50W,100W,200W,400W,600W,750W,1000W	Motor main circuit cable	Motor with brake	3m	EL-MSA00-03-E EL-MMA00-03-E
			5m	ELMSA00-05-E EL-MMA00-05-E
			10m	ELMSA00-10-E EL-MMA00-10-E
			20m	EL-MSA00-20-E EL-MMA00-20-E
			3m	EL-MMA00-03-E
			5m	EL-MMA00-05-E
			10m	EL-MMA00-10-E
			20m	EL-MMA00-20-E
	Encoder cable	2500 line-saving encoder cable	3m	EL-PE700-03-E
			5m	EL-PE700-05-E
			10m	EL-PE700-10-E
			20m	EL-PE700-20-E
		Communication incremental encoder cable	3m	EL-PI700-03-E
			5m	EL-PI700-05-E
			10m	EL-PI700-10-E
			20m	EL-PI700-20-E
		Communication absolute value encoder cable	3m	EL-PA700-03-E
			5m	EL-PA700-05-E
			10m	EL-PA700-10-E
			20m	EL-PA700-20-E

Servo option

Model of Servo Motor	Name	Order
EAM-SF/TF/TH-A5,01,02,04,06,08,10 50W,100W,200W,400W,600W,750W,1kW	Standard cable connector for motor main circuit	EU-M00
	Cable connector for electric motor main circuit	EU-M01
	2500 line saving encoder cable connector	EU-P00
	Communication absolute encoder cable	EU-P01
	Battery options	EU-B00


Communication cable option

Model	Description
EL-CN700-01-E	PC communication cable of servo driver
EL-CN01-A3-E	Multi-machine parallel communication cable for servo driver

Control cable option

Model	Description
EL-CA700-01-E	Servo CN1 I/O signal cable
EU-C01	Servo CN1 terminal accessories

Description on definition of driver terminal



Description on CN1 Pins

Pin No.	Name	Abbreviation	Description
1	Internal 24V Power Supply Positive	+24V	It is only used for internal DI and pulse input pull-up, and cannot supply power to external relay brake etc.
2	Digital Output 1 (Negative)	DO1-	Digital output can be freely configured with functions and output logic according to user's requirements. When wiring, if relay needs to add freewheeling diode, if opt coupler accepts, it needs to connect current limiting resistor. Incorrect wiring will cause the DO port hardware to burn out.
3	Digital Output 2 (Negative)	DO2-	
4	Digital Output 3 (Negative)	DO3-	
5	Digital Output 4 (Negative)	DO4-	
6	Digital Output 5 (Negative)	DO5-	
7	Pulse Direction Signal (Negative)	SIGN-	For differential input, the maximum frequency is 4MHZ and 500KHZ for open-circuited collector.
8	Pulse Count Signal (Negative)	PULSE-	
9	Pulse Command Input Internal Resistor Common Terminal	PULLHI	When the pulse connection is open-circuited collector, PNP pin is connected to COM-, and NPN to 24V
10	Frequency Division Output Phase B (Positive)	PBO+	The number of pulses output by one revolution of the motor is set by P02.03, and the number of frequency division outputs is set to be the number after 4 times of frequency multiplication.
11	Frequency Division Output Phase A (Positive)	PAO+	
12	Phase Z Open-circuited Collector Output	OCZ	The motor rotates one revolution to output a Z pulse, the level is set by P02.05, and the output is open collector.
13	485 Communication (Positive)	RS485+	RS485+
14	5V Power Supply Reserved by Manufacturer	+5V	The manufacturer reserves 5V power supply, which is forbidden to use.
15	5V Power Supply Reference Ground Reserved by Manufacturer	GND	The manufacturer reserves 5V power supply, which is forbidden to use.
16	Ground Corresponding to 24V	COM-	Internal 24V power reference ground.
17	DI Common Input	COM+	When DI uses internal 24V power supply, this


Pin No.	Name	Abbreviation	Description
	Terminal		pin is short circuited to internal 24V pin (1).
18	Digital Output 1 (Positive)	DO1+	For digital output, functions and output logic can be freely configured according to user's requirements. When wiring, if the relay needs to be added with freewheeling diode, such as optocoupler, it needs to be connected with current limiting resistor. Incorrect wiring will cause the DO port hardware to burn out
19	Digital Output 2 (Positive)	DO2+	
20	Digital Output 3 (Positive)	DO3+	
21	Digital Output 4 (Positive)	DO4+	
22	Digital Output 5 (Positive)	DO5+	
23	Pulse Direction Signal (Positive)	SIGN+	Incaseof differential input, the maximum frequency is 4MHZ, and 500KHZ for open-circuited collector.
24	Pulse Count Signal (Positive)	PULSE+	
25	Frequency Division Output Phase B (Negative)	PBO-	The number of pulses output for one revolution of the motor is set by P02.03, and the number of frequency division outputs is set to be the number after 4 times of frequency multiplication.
26	Frequency Division Output Phase B (Negative)	PAO-	
27	Signal Ground	GND	When the pulse command input is in differential mode, the signal ground is connected with the signal ground of the upper computer, and the pulse frequency division output signal ground is connected with the signal ground of the upper computer.
28	485 Communication (Negative)	RS485-	RS485-
29	Analog Output Reference Ground	GND	Analog output reference ground.
30	Analog Input	AI	The other end of the analog input channel is connected to pin 29.
31	Internal 24V Power Reference Ground	COM-	Internal 24V power reference ground
32	Digital Input 8	DI8	For digital quantity input, functions and input level logic can be freely configured according to user's requirements. During wiring, internal 24v or external 24V can be selected according to different working conditions, and different connection modes can be selected according to PNP type and NPN type.
33	Digital Input 7	DI7	
34	Digital Input 8	DI6	
35	Digital Input 9	DI5	
36	Digital Input 4	DI4	
37	Digital Input 3	DI3	
38	Digital Input 2	DI2	

Pin No.	Name	Abbreviation	Description
39	Digital Input 1	DI1	
40	Frequency Division Output Phase Z(Negative)	PZO-	For one revolution of the motor, a z pulse is output and the level is set by P02.05, with a differential 5V signal to be output.
41	Frequency Division Output Phase Z (Positive)	PZO+	
42	485 Communication (Negative)	RS485-	Internal connection to pin 28
43	485 Communication (Positive)	RS485+	Internal connection to pin 13
44	RS485 Communication Signal Ground	GND	RS485 Communication Signal Ground

3.3 Wiring of connector CN1

Connection with upper controller



Example for typical wiring of connector CN1



Connection of RS485 communication signals

Symbols	Connector pin number	Function
485+	43	RS485 I/O signal
485-	42	
GND	44	RS485 communication station

RS485 communication is used to connect one host and multiple TDS-R*, with P09.00 for each TDS-R* to be set to the value of 0 ~ 127.



Note:



To determine the location of the signals between the servo drives, connect the GND of each drive

Connection of control input signal



Symbol	Function	Connector pin	Description
DI1	SRV_ON	39	Servo enable
DI2	POT (Non default)	38	Positive limit
DI3	NOT (Non default)	37	Negative limit
DI4	JogCmdP(Non default)	36	Positive jog
DI5	JogCmdN(Non default)	35	negative jog
DI6	A_Clr (Non default)	34	Failure reset
DI7	ORGP(Non default)	33	home switch
DI8	Execute_Homing(Non	32	Trigger homing enable
+24V	+24V	1	Internal 24V power supply, with a voltage range of +20~28V, and a power supply input(12V~24V)
COM-	COM-	31	
COM+	COM+	17	

Taking DI1 as an example, other DIs are connected in the same way.



When the higher-level device is a relay output



When the higher-level device is NPN open-circuited collector output



When the higher-level device is PNP open-circuited collector output



Note: Incompatible with PNP input to be used in combination with NPN input.

Connection of pulse command input signals

Symbol	Connector pin	Description
PULSE+	24	Pulse instruction input
PULLHI	9	Common terminal of built-in resistor for pulse
GND	27	Signal ground

The driver is compatible with the long-line driver interface and the open-circuited collector output interface, with the corresponding input maximum frequency and minimum pulse width as shown in the following table:


PULS/SIGN signal pulse input mode	Allowable input maximum frequency	Min necessary pulse width(μ s)
Open-circuited collector interface	200k pulse/s	2.5
Long line differential driver	4M pulse/s	0.125

Note: If the output pulse width of the upper device is less than the minimum pulse width value, the driver will receive the pulse incorrectly.

In order to reduce the impact of noise, please use twisted pair shielded wire, with the wiring length to be controlled within 1 m.



When the host device is a differential driver output

This is a signal transmission mode that is not easily affected by noise, which is therefore recommended to improve the accuracy of signal transmission.





When the upper device is open-circuited collector


In case of using the driver's built-in 24V power supply



In case of using an external 24V power supply and the driver's internal resistor



When using external 12V and 24V power supplies and external resistors




VDC	The specifications of the R	$\frac{VDC-1.5}{R+220} = 10mA$
12V	820Ω 0.5W	
24V	2kΩ 0.5W	

Connection of analog command input signals

Symbol	Connector pin	Description
AI	30	Ordinary analog input signal, with a resolution of 12 bits and an input voltage of -10V~+10V.
GND	29	Analog input signal ground.

The corresponding command of Analog input voltage value is set by P05 group.
 Maximum allowable input voltage range: -10V~+10V;
 A/D conversion resolution: 12bit;
 Input impedance: appr 9kΩ.




Connection of control output signal

Symbol	Function	Connector pin	Description
DO1+	Alm+	18	Fault output signal
DO1-	Alm-	2	
DO2+	Blk+	19	Brake signal
DO2-	Blk-	3	
DO3+	Son+	20	Servo enable status output
DO3-	Son-	4	

DO4+	INP+	21	Positioning OK output
DO4-	INP-	5	
DO5+	HomeOK+	22	Homing OK output
DO5-	HomeOK-	6	

Taking DO1 and DO5 as examples, other DOs are connected in the same way.



Connection of frequency division pulse output signal


Symbol	Connector pin	Function
PAO+	11	Phase-A frequency division output signal
PBO+	10	Phase-B frequency division output signal
PZO+	41	Phase-Z frequency division output signal
OCZ	12	Phase-Z frequency division output signal
GND	27	Home pulse open-circuited collector output signal ground
+5V	14	Manufacturers-reserved 5V power supply shall not be used
GND	15	

The driver provides differential driver interface and Z-phase pulse open collector output interface.

Differential driver output

The encoder signal outputs (A phase, B phase, Z phase) after frequency division processing are differentially output through a long-line driver.


When receiving with a long-line receiver on the upper device side, be sure to install a termination resistor (about 330 Ω is recommended) at the input of the long-line receiver. When receiving with opt coupler circuit, please use high-velocity optocoupler and limit the line current to 20mA.



Open-circuited collector output


This interface is the open-circuited collector interface of encoder phase-Z frequency division output signal and is non-insulated interface.

Since the pulse width of phase-Z signal is narrow, please use a high-velocity photocoupler to receive the signal on the upper device side.



Connection of brakesignals

Symbol	Function	Connector pin	Description
DO2+	Blk+	19	Brake signal
DO2-	Blk-	3	



Note: The 24V power supply should be in the scope of supply of users.

Precautions for use and wiring of brakes

- ▶ For the length of the motor brake cable, the voltage drop caused by cable resistance should be fully considered, and the input voltage should be at least 21.6V for brake operation.
- ▶ For the brake, it is better not to share power with other electrical appliances to prevent the brake from misoperation due to voltage or current reduction caused by the work of other electrical appliances.
- ▶ Cables with specifications above 0.5 are recommended.
- ▶ See Section 5.2 for timing chart of brake enable and relevant function code settings.
- ▶ The braking mechanism built into the servo motor is a fixed special mechanism of non-energized action type, which cannot be used for braking purposes and can only be used when the servo motor is kept in a stopped state.
- ▶ After the servo motor is shut down, turn off "servo enable" (S-ON).
- ▶ When the motor with the built-in brake is running, the brake may make a click sound, and the function is not affected.
- ▶ When the brake coil is energized (the brake is in an open state), magnetic flux leakage may occur at the Axes end and other parts. Please pay attention when using magnetic sensors and other instruments near the motor.


3.4 Wiring of connector CN2

Connection with upper PC


CN2 is the communication interface between the driver and PC for connecting the computer and USB, which can be used for parameter setting change and monitoring, etc.

PC communication cable: USB mini-B (commercially available)


Symbol	Connector pin	Description
V-BUS	1	An empty pin, which should not be connected
D-	2	Data signal line
D+	3	
ID	4	Not to be connected
GND	5	Signal ground




3.5 Wiring of connector CN3

Application	Connector pin No.	Symbol	Description
	1	5V	Power supply for encoder.
	2	GND	Power ground, which should be connected to the internal signal ground of the driver.
	3	A+	Encoder's phase-A signal (twisted pair)
	4	A-	
	5	B+	Encoder's phase-B signal (twisted pair)
	6	B-	
	7	Z+	Phase-Z's zero pulse signal (twisted pair)
	8	Z-	
	9	PTC+	Temperature sampling signal (no PTC)
	10	COM	Temperature sampling signal reference
Housing	PE	To be connected with PE terminal inside	

Connection with incremental encoder




3.6 Wiring of connector CN4


Application	Connector pin number	Symbol	Description
	1	5V	Encoder +5V power supply
	2	GND	
	3	PS+	Serial data transceiving signal
	4	PS-	
	5	CLK+	Serial clock transmission signal
	6	CLK-	
	7	HALL-U	--
	8	HALL-V	--
	9	HALL-W	--
	10	--	Empty
Housing	PE		To be connect with PE terminal inside the driver.

Connection with bus encoder


In case of application of single-ring absolute position encoder:



Application of multi-ring absolute position encoder:




Key Points of wiring for communication encoder



- The cable length between the driver and the motor shall be within 20 m.
- The distance between the main circuit wiring and the main circuit wiring shall be more than 30cm, and they shall not be bundled together in the sleeve.
- Please set the input power voltage of the connector on the encoder side within the range of dc4.90v ~ 5.25V.

○ Tips for making encoder cable by yourself:

① Refer to the wiring diagram.



② Wire: the core diameter of the wire used shall be more than 0.18mm (awg24), and it shall be equipped with bending resistant twisted pair with shielding layer.

③ Twisted pair shall be used for wiring relative to signal / power supply.

④ Shielding treatment

-Shielding layer on driver side: to be welded to the shell of connector CN4.


-Shielding layer on motor side: (pin 1 of AMP 9 pin of SF series motor)


⑤ Do not connect the redundant terminals of each connector

3.7 Wiring of connector CN5

Connection of main circuit terminal

Description on definition for interface of connector CN5

Terminal	Terminal name	Terminal function
U、V、W	Servo motor connection terminal	The connection terminal of servo motor shall be connected with U, V and W of motor.
L1、L2	Main circuit power input terminal	For single-phase power input of main circuit, AC220V power supply shall be connected between L1 and L2.
N	DC bus negative voltage terminal	Do not connect the DC bus terminals of the driver when the single unit is running.
P、C	Braking resistance connection terminal	External brake resistance connection terminal.
	Grounding	Two ground terminals, to be connected with a power supply grounding terminal and a motor grounding terminal.



For the wiring of the main circuit and its precaution, please refer to Chapter 3 → Description on System Wiring and Its Main Points (P23).

Selection of braking resistors and precautions for wiring;


- ▶ Do not connect the external braking resistor directly to the positive pole P and negative pole N of the bus, otherwise it will cause explosion and fire.
- ▶ Please confirm that braking resistor's parameters P02-20, P02-21 and P02-22 have been correctly set before using the driver.
- ▶ Please install external braking resistor on non-combustible materials such as metal.

3.8 Wiring of connector on motor side


Wiring of cables for EAM-S/T series motor

Connection of encoder cable for EAM-S/T series motor

Connector outline




Terminal pin distribution of the encoder cable




Stitch number	Signal name	
1	BAT+	Battery+
2	BAT-	Battery -
3	PE	Shielding
4	PS+	Serial data line
5	PS-	
6	-	Empty
7	+5V	Power supply for encoder
8	GND	Power supply ground

Connection of power cables for EAM-S/T series motor

Outline sketch of connector




Distribution of terminal pins of power lines



Pin No.	Signalname	
1	U	Power line of motor
2	V	
3	W	
4	PE	Ground wire

Chapter 4 Display and Operation of Panels

4.1 Introduction to keys on panel



The panel of the servo driver consists of a display (LED digital tube) and keys, which can be used for various types of display of the servo driver, with the Group-P parameter setting for as an example to show the typical functions of the display keys as follows:

Table 4-1 Introduction to typical functions of keys

Keys	Typical functions
MODE	Used to change operating modes and parameter
UP	Used to increase the selected number (flashing number)
DOWN	Used to decrease the selected number (flashing number)
SHIFT	Used to move the selected number (flashing number) to the left or turn the page to the upper position.
SET	Used to enter the next menu or set parameters, etc.

4.2 Change of operation mode

The servo running status is displayed on the panel by default.




Figure 4-1 State Switching of Panel by Default

Press the key Mode to switch the level-1 menu of the panel, and after powered on, the default display menu of the panel is the status display.

Status display: To display the current status of the servo:

Servo has not got ready	nordy
Servo has already got ready	rEAdy
Servo has been enabled and available for operation	Su_on
Servo gives an alarm, displaying fault code	Al.xx.Y

Figure 4-2 Operation and Display of Level 1 Menu on Panel

4.3 Setting of parameters for group P

Parameter setting: Let servo enter parameter setting mode. This group is used when servo parameter need to be changed, with P02.03 as an example:




Fig. 4-3 Procedures for Setting Parameters

4.4 Display of parameter for group U

Monitoring display: An observation group for servo operation parameter, in which real-time displays such as servo velocity, DI, DO, current, temperature, etc. are provided

For example, select U00.20 to display the number of servo input pulses




Fig. 4-4 Description on Operation of Parameter for Group U

For example: Select U00.01 to display the DI status of servo input




Figure 4-5 Description on DI Display

Note: The rightmost display of DI status indicates DI1 status, which, starting from the second on the right of DI2 status, sequentially corresponds to DI1 to DI8 from the right to the left.

4.5 Description on use of parameter of group F

Monitoring display: Servo auxiliary function group

For example, use of the jog function on the panel.





Figure 4-6 Description on Operation of Commissioning Panel

For example: Function of inertia identification



4.6 Fault display

Fault display :

Display	Name	Contents
AL.10.1	Current warning code	AL.: There is currently a drive failure or warning 10.1: Fault code (encoder fault)

AL.XX.Y, where XX indicates the fault category and Y indicates the sub-fault code.

Chapter 5 Control and Timing Sequence

5.1 Diagram for timing sequence of powering on

Diagram for timing sequence of powering on (timing sequence of receiving servo enable signal)




Figure 5-1 Timing sequence of receiving servo enable signal when powering on

t_2 is the charging time (80ms) of the internal driver bootstrap circuit; the host device can not issue a command until it receives the enable DO fed back from the servo, or will delay for more than 80 ms.

5.2 Diagram for timing sequence of brake enable




Fig.5.2 Diagram for Timing Sequence of Servo enable with Brake when Receiving Command

t_1 is the action time of the brake.

t_2 is the time set by P02.19, and before which the command from the host device cannot be accepted

t_3 is the time set by P02.1A, which is the enable time of the delay time period from when the brake is effective to when the motor is de-energized; when the delay time reaches the set time t_4 (P02.1C) or the velocity is less than (P02.1B set), the brake is effective

t_5 is the charging time of the internal servo bootstrap circuit

Relevant function code of brake

P02.18 Brake enable	Setting range	Unit	Factory default	Related mode		
	0~1	-	0	P	S	T

Notes :

0-Not enable brake
1-Enableing brake

After enable brake, use FunOut.6 (BKout) output to control external relay (P06.02=6)

P02.19 Delay from brake ineffective to command receiving	Setting range	Unit	Factory default	Related mode		
	0~500	ms	200	P	S	T

Note:

After receiving the servo enable command, the brake is ineffective. Due to the action of the brake relays, the command can be received with a delay of some time.

P02.1A Delay from brake effective to motor getting off	Setting range	Unit	Factory default	Related mode		
	50~1000	ms	150	P	S	T

Note:

Effective movement of the brake; Due to the delay in the operation of the brake relay, the output of the motor needs to be disabled for a period of time.

P02.1B Effective velocity threshold of brake	Setting range	Unit	Factory default	Related mode		
	20~300	rpm(*mm/s)	30	P	S	T

Note:

In order to ensure that the brake can effectively execute the braking action after the velocity is lower than the set value

* Represent a linear motor unit

P02.1C Delay from servo enable command to brake effective	Setting range	Unit	Factory default	Related mode		
	1~1000	ms	500	P	S	T

Note:

After the servo receives the external disable command, it will delay for a period of time to perform the braking action

5.3 Diagram for timing sequence of shutdown




Figure 5-3 Diagram for Timing Sequence of Servo Shutdown

Function codes related to shutdown

P02.10 Disable shutdown mode	Setting range	Unit	Factory default	Related mode		
	-2~2	-	0	P	S	T

Notes:

The mode of servo disable shutdown should be changed according to the actual situation

-2 : Slope shutdown, with DB braking

-1 : DB shutdown DB status

0 : Free shutdown, keeping operating freely.

1 : Slope shutdown, keeping operating freely.

2 : Zero-velocity shutdown, keeping operating freely.

P02.11 Over travel stop mode	Setting range	Unit	Factory default	Related mode		
	0~1	-	1	P	S	T

Changes are generally not recommended

P02.12 Non-resettable failure shutdown mode	Setting range	Unit	Factory default	Related mode		
	0~2	-	1	P	S	T

Notes:

Shutdown mode in case of non-resettable failure

0-shutting down freely

1-DB shutdown free state

2-DB shutdown, keeping DB state

P02.13 Resettable fault shutdown mode	Setting range	Unit	Factory default	Related mode		
	-4~3	-	1	P	S	T

Notes:

Resettable shutdown mode in case of failure :

-4-Emergency torque shutdown, keeping DB State

-3-Slope shutdown, keeping DB State

-2-Slope shutdown, keeping DB State

-1-DB shutdown, keeping DB state

0-Free shutdown, keeping operating freely.

1-Slope shutdown, keeping operating freely.

2-Slope shutdown, keeping operating freely.

3-Emergency torque shutdown, keeping operating freely

P02.14 Shutdown mode and shutdown state switching velocity condition value	Setting range	Unit	Factory default	Related mode		
	10~1000	Rpm (*mm/s)	100	P	S	T

Notes:

When the actual running velocity of the motor is less than the threshold value, it is judged as a shutdown state.

*stands for linear motor's unit

P07.20 Slope shutdown acceleration and deceleration time	Setting range	Unit	Factory default	Related mode		
	0~10000	ms	50	P	S	T

Notes:

Slope shutdown acceleration and deceleration time when the fault shutdown or servo off shutdown occurs

P07.21 Emergency shutdown acceleration and deceleration time	Setting range	Unit	Factory default	Related mode		
	10~1000	ms	5	P	S	T

Notes:

Acceleration and deceleration time in case of emergency shutdown mode

P07.22 Emergency torque shutdown deceleration	Setting range	Unit	Factory default	Related mode		
	0~3000	0.1%	500	P	S	T

Change of slope torque in case emergency torque shutdown

5.4 Release Function Setting

When the inertia of external load is large (more than 5 times) and there is a large deceleration, it is necessary to use the release function to release the excessive bus voltage. Release the resistance value and power of the resistor appropriately as the instructions.

Release-setting related function codes

P02.20 Release resistor's use mode	Setting range	Unit	Factory default	Related mode		
	0~3	-	1	P	S	T

Notes:
 0-Built in resistor
 1-External resistor
 2-Air cooling of external resistor
 3-No release

P02.21 External release resistor's power	Setting range	Unit	Factory default	Related mode		
	1~65535	w	800	P	S	T

Notes:
 If the power is too small, the release resistor will overheat or overload

P02.22 External release resistor's resistance value	Setting range	Unit	Factory default	Related mode		
	1~1000	Ω	50	P	S	T

Notes:
 The resistance value of the release resistor should be selected appropriately and should generally be 40-50 ohms; if the value is too small, the driver will be over-current, which will greatly affect the release effect.

P02.26 Resistor's heat dissipation coefficient	Setting range	Unit	Factory default	Related mode		
	1~1000	0.1%	600	P	S	T

Notes:
 The release resistor's resistance value and heat dissipation coefficient. The larger the setting, the better the heat dissipation effect of the release resistor, and the overload of the release resistor can be limited to a certain extent.

Chapter 6 Control Mode

All control modes are described as follows: :




Fig. 6-1 Block Diagram for 3-Loop Control

By processing the input (pulse, analog quantity, communication, etc.) and feedback signals, the driver can accurately and rapidly control the position, velocity and torque of the motor, and support the real-time switching control of the above modes, of which, the position control has found widest application in servo system.

6.1 Position Control Pulse Mode




Fig. 6-2 Diagram for Source of Position Mode Pulse Command

The position control pulse mode mainly includes the following steps:

1. Installation wiring includes: servo enable (SRV_ON), pulse input (Puls+-, Sign+-), positioning OK (INP), servo enable output (Son), etc.
2. Set operation mode (P02.00 = 1), position mode
3. Set pulse input mode (P03.02), electronic gear ratio, etc.
4. Set DI and DO related functions
5. Other basic settings (release resistor, shutdown mode, etc.)

6.1.1 Position Control Pulse Mode Input Setting








Figure 6-3 Position Mode Pulse Command Input Settings

P03.00 Command pulse format	Setting range	Unit	Factory default	Related mode		
	0~1	-	0	P	S	T
Notes: 0-Impulse command 1-Internal position						

P03.02 Command pulse format	Setting range	Unit	Factory default	Related mode		
	0~3	-	0	P	S	T

Notes:

Command format setting	Pulse format	positive pulse diagram	negative pulse diagram
0	Pulse + direction positive logic		
1	Pulse + direction negative logic		
2	Phase A+Phase B Orthogonal Pulse Quadruple Frequency	<p>Phase A is ahead of Phase B by 90°</p>	<p>Phase B is ahead of Phase A by 90°</p>

3	CW+CC W	CW 
		CCW 
		CW 
		CCW 

P03.04 Input pulse hardware filtering time	Setting range	Unit	Factory default	Related mode		
	0~255	25ns	10	P	S	T
Notes:						
The hardware filtering time can be set according to the frequency of the input pulse, which can filter out external interference signals to a certain extent.						
General situation:						
Set to 4 in case of more than 3M						
Set 10 in case of less than 1M						
Set to 20 in case of less than 500K						

6.1.2 Electronic Gear Ratio in Position Control Pulse Mode

Number of pulses in actual operation of the motor:

$$\text{Input pulses} * \frac{\text{Electronic gear ratio numerator}}{\text{Electronic gear ratio denominator}} = \text{Actual operating pulse number}$$

P03.10 Number of command pulses per revolution of motor	Setting range	Unit	Factory default	Related mode		
	0~8388608	-	1000	P	S	T

Notes:

Directly specify the number of command pulses to be sent for one revolution of the motor.

The numerator equivalent to the electronic gear ratio is P03.10, and the denominator of the electronic gear ratio is the number of pulses per revolution of the encoder

*Notes to linear motor

P03.10 Number of command pulses for motor moving one pole distance (N-N)	Setting range	Unit	Factory default	Related mode		
	0~8388608	-	0	P	S	T

Notes:

Directly specify the number of command pulses to be sent for one pole distance of movement of the motor .

The numerator equivalent to the electronic gear ratio is P03.10, and the denominator of the electronic gear ratio is one pole distance pulse number of grating scale (magnetic grating scale)

If P03.10 = 0, P03.12 and P03.14 take effect.

P03.12 Electronic gear ratio 1 (numerator)	Setting range	Unit	Factory default	Related mode		
	1~ 1072741824	-	10	P	S	T

Note:
Setting the numerator for the 1st group of electronic gear ratios.

P03.14 Electronic gear ratio 1 (numerator)	Setting range	Unit	Factory default	Related mode		
	1~ 1072741824	-	1	P	S	T

Notes:
Setting the numerator for the 1st group of electronic gear ratios

P03.16 Electronic gear ratio 2 (numerator)	Setting range	Unit	Factory default	Related mode		
	1~ 1072741824	-	10	P	S	T

Notes:
Setting the numerator for the 2nd group of electronic gear ratios.

P03.18 Electronic gear ratio 2 (denominator)	Setting range	Unit	Factory default	Related mode		
	1~10727418 24	-	1	P	S	T

Notes:
Setting the denominator for the 2st group of electronic gear ratios

Electronic gear ratio supports DI switching:

For DI input function FunIN.17 (GearSw), the first group of electronic gear ratios is used when GearSw is ineffective, and the second group of electronic gear ratios is used when GearSw is effective.

Setting range of electronic gear ratio:

Rotary motor :

$$2.5 \leq \frac{\text{gear ratio numerator}}{\text{gear ratio denominator}} * \frac{\text{number of pulse for one revolution of encoder}}{\leq 10000000}$$

*Linear motor :

$$2.5 \leq \frac{\text{gear ratio numerator}}{\text{gear ratio denominator}} * \frac{\text{number of pulse for one pole distance}}{\text{pole distance}} \leq 10000000$$

Otherwise, it will alarm AL.045 electronic gear ratio setting error.

6.1.3 Position Command Filtering Setting

When the host device pulse needs to be smoothed, software filtering can be added:

P03.06 Command FIR filtering time constant	Setting range	Unit	Factory default	Related mode		
	0~65535	0.01ms	0.0	P	S	T

Notes:

Setting the time constant of FIR filter for position command

P03.07 Average filtering time constant	Setting range	Unit	Factory default	Related mode		
	1~1280	0.1ms	0.0	P	S	T

Notes:

Setting the time constant of the average filter for the position command (encoder unit)

6.1.4 Setting of Input and Output in Position Control Pulse Mode

Location DI input

Pulse inhibits function:

For the DI input function FunIN.18 (INH), when the INH is effective, the pulse command is no longer received.

Frequency division output setting.

P02.02 Phase of frequency division output pulse	Setting range	Unit	Factory default	Related mode		
	0~1	-	0	P	S	T

Notes:

Setting the phase relationship between phase-A pulse and phase-B of pulse output.

0-positive frequency division

1-negative frequency division

P02.03 Number of frequency division pulses of encoder	Setting range	Unit	Factory default	Related mode		
	10~1048576	p/revolution (*p/pole)	1024	P	S	T

Notes:

For the number of pulses of output of phase A and phase B per revolution of the motor, the number of pulses after quadruple frequency is $4 \times P02.03$.

Unit of linear motor is p/pole.

P02.04 Selection of Z Pulse Output Polarity	Setting range	Unit	Factory default	Related mode		
	0~1	-	1	P	S	T

Notes:

Setting the output level when the Z-phase pulse is effective

0- Positive polarity Output

(Z pulse is at high level)

1- Negative polarity output

(Z pulse is at low level)

Position OK output related function code

P06.2C Positioning completion range	Setting range	Unit	Factory default	Related mode		
	1~65535	-	100	P	S	T

Notes:

At the end of transmission of the position command, when the position deviation is $|\leq P06.2C$, and held for a time period of $P06.2D$, the positioning completion signal FunOut.3(INP) is output.

The Unit for this parameter is determined by P06.2E:

P06.2E=0 is user Unit, i.e. gear ratio

P06.2E=1 is encoder Unit

P06.2D Waiting time after positioning completion	Setting range	Unit	Factory default	Related mode		
	0~2000	ms	0	P	S	T

Notes:

At the end of transmission of the position command, when the |position deviation is $|\leq P06.2C$, and held for a time period of $P06.2D$, the positioning completion signal FunOut.3(INP) is output.

The Unit for this parameter is determined by P06.2E:

P06.2E=0 is user Unit, i.e. gear ratio

P06.2E=1 is encoder Unit

P06.2E Position Reaching Window Unit Setting	Setting range	Unit	Factory default	Related mode		
	0~1	-	0	P	S	T


Notes:

Setting the unit of the position reaching threshold

0- User Unit

1-Encoder unit

6.2 Position control homing mode



The homing mode is used to find the mechanical home, the Z signal of the motor, or designate a fixed position as the home, for setting of the initial position of operation.

Description on homing function


Related function code:

P03.31 Homing model	Setting range	Unit	Factory default	Related mode		
	0~36	-	1	P	S	T

Notes:


Fully compatible with the homing mode of CanOpen402 (Cia402) protocol, as shown in the following table

Homing mode 1 (Mode 17)




1. Operate in the negative direction to find the rising edge of the negative limit switch (high velocity switched to low velocity).
2. Operate in the positive direction to find the falling edge of the negative limit switch.
3. Operate in the positive direction to find the Z signal. (not to find Z signal in mode 17).

Homing mode 2 (mode 18)




1. Operate in the positive direction to find the rising edge of the positive limit switch (high velocity switched to low velocity).
2. Operate in the negative direction to find the falling edge of the positive limit switch.
3. Operate in the negative direction to find the Z signal. (not to find Z signal in mode 18)

Homing mode 3(mode 19)




1. Operate in the positive direction to find the rising edge of the home switch (high velocity switched to low velocity).
2. Operate in the negative direction to find the falling edge of the home switch (on the same side).
3. Operate in the negative direction to find the Z signal. (not to find Z signal in mode 19)

Homing mode 4(mode 20)




1. Operate in the negative direction to find the rising edge of the home switch (high velocity switched to low velocity).
2. Operate in the positive direction to find the falling edge of the home switch (on the same side).
3. Operate in the negative direction to find the rising edge of the home switch.
4. Operate in the negative direction to find the Z signal. (not to find Z signal in mode 20)

Homing mode 5(mode 21)




1. Operate in the negative direction to find the rising edge of the home switch (high velocity switched to low velocity).
2. Operate in the positive direction to find the falling edge of the home switch (on the same side).
3. Operate in the positive direction to find the Z signal. (not to find Z signal in mode 21)

Homing mode 6(mode 22)




1. Operate in the positive direction to find the rising edge of the home switch (high velocity switched to low velocity).
2. Operate in the negative direction to find the falling edge of the home switch (on the same side).
3. Operate in the positive direction to find the rising edge of the home switch.
4. Operate in the positive direction to find the Z signal. (not to find Z signal in mode 22)

Homing mode 7(mode 23)




1. Operate in the positive direction to find the rising edge of the home switch (high velocity switched to low velocity).
2. Operate in the negative direction to find the falling edge of the home switch (on the same side).
3. Operate in the negative direction to find the Z signal. (not to find Z signal in mode 23)

or




1. Operate in the positive direction to find the rising edge of the positive limit switch.
2. Operate in the negative direction to find the rising edge of the home switch (high velocity switched to low velocity).
3. Operate in the negative direction to find the falling edge of the home switch.
4. Operate in the negative direction to find the Z signal. (not to find Z signal in mode 23)

Homing mode 8(mode 24)




1. Operate in the positive direction to find the rising edge of the home switch (high velocity switched to low velocity).
2. Operate in the negative direction to find the falling edge of the home switch (on the same side).
3. Operate in the positive direction to find the rising edge of the home switch.
4. Operate in the positive direction to find the Z signal. (not to find Z signal in mode 24)

Or:




1. Operate in the positive direction to find the rising edge of the positive limit switch.
2. Operate in the negative direction to find the rising edge of the home switch (high velocity switched to low velocity).
3. Operate in the negative direction to find the falling edge of the home switch.
4. Operate in the positive direction to find the rising edge of the home switch.
5. Operate in the negative direction to find the Z signal. (not to find Z signal in mode 24).

Homing mode 9(mode 25)




1. Operate in the positive direction to find the rising edge of the home switch (high velocity switched to low velocity).
2. Operate in the positive direction to find the falling edge of the home switch (on the other side).
3. Operate in the negative direction to find the rising edge of the home switch.
4. Operate in the negative direction to find the Z signal. (not to find Z signal in mode 25)

or




1. Operate in the positive direction to find the rising edge of the positive limit switch.
2. Operate in the negative direction to find the rising edge of the home switch (high velocity switched to low velocity).
3. Operate in the positive direction to find the falling edge of the home switch.
4. Operate in the negative direction to find the rising edge of the home switch.
5. Operate in the negative direction to find the Z signal. (not to find Z signal in mode 25).

Homing 10(mode 26)




1. Operate in the positive direction to find the rising edge of the home switch(high velocity switched to low velocity).
2. Operate in the positive direction to find the falling edge of the home switch(on the same side)
3. Operate in the negative direction to find the rising edge of the home switch.
4. Operate in the positive direction to find the failing edge of the home switch.
5. Operate in the positive direction to find the Z signal. (not to find Z signal in mode 26)

or




1. Operate in the positive direction to find the rising edge of the positive limit switch.
2. Operate in the negative direction to find the rising edge of the home switch(high velocity switched to low velocity).
3. Operate in the positive direction to find the failing edge of the home switch.
4. Operate in the negative direction to find the rising edge of the home switch.
5. Operate in the positive direction to find the falling edge of the home switch.
6. Operate in the positive direction to find the Z signal. (not to find Z signal in mode 26)

Homing mode 11(mode 27)




1. Operate in the negative direction to find the rising edge of the home switch (high velocity switched to low velocity).
 2. Operate in the positive direction to find the falling edge of the home switch (on the same side).
 3. Operate in the positive direction to find the Z signal. (not to find Z signal in mode 27)
- or




1. Operate in the negative direction to find the rising edge of the negative limit switch.
2. Operate in the positive direction to find the rising edge of the home switch (high velocity switched to low velocity).
3. Operate in the positive direction to find the rising edge of the home switch.
4. Operate in the positive direction to find the Z signal. (not to find Z signal in mode 27)

Homing mode12(mode28)




1. Operate in the negative direction to find the rising edge of the home switch (high velocity switched to low velocity).
 1. Operate in the positive direction to find the falling edge of the home switch (on the same side)
 2. Operate in the negative direction to find the rising edge of the home switch.
 3. Operate in the negative direction to find the Z signal. (not to find Z signal in mode 28)
- or




1. Operate in the negative direction to find the rising edge of the negative limit switch.
2. Operate in the positive direction to find the rising edge of the home switch (high velocity switched to low velocity).
3. Operate in the positive direction to find the falling edge of the home switch.
4. Operate in the negative direction to find the rising edge of the home switch.
4. Operate in the negative direction to find the Z signal. (not to find Z signal in mode 28)

Homing mode 13(mode 29)




1. Operate in the negative direction to find the rising edge of the home switch (high velocity switched to low velocity).
2. Operate in the negative direction to find the falling edge of the home switch (on the other side).
3. Operate in the positive direction to find the rising edge of the home switch.
4. Operate in the positive direction to find the Z signal. (not to find Z signal in mode 29)

or




1. Operate in the negative direction to find the rising edge of the negative limit switch.
2. Operate in the positive direction to find the rising edge of the home switch (high velocity switched to low velocity).
3. Operate in the negative direction to find the falling edge of the home switch.
4. Operate in the positive direction to find the rising edge of the home switch.
5. Operate in the negative direction to find the Z signal. (not to find Z signal in mode 29)

Homing mode 14(mode 30)



1. Operate in the negative direction to find the rising edge of the home switch(high velocity switched to low velocity).
2. Operate in the negative direction to find the falling edge of the home switch(on the other side).
3. Operate in the positive direction to find the rising edge of the home switch.
4. Operate in the negative direction to find the falling edge of the home switch.
5. Operate in the negative direction to find the Z signal. (not to find Z signal in mode 30)

or



1. Operate in the negative direction to find the rising edge of the negative limit switch.
2. Operate in the positive direction to find the rising edge of the home switch(high velocity switched to low velocity).
3. Operate in the negative direction to find the falling edge of the home switch.
4. Operate in the positive direction to find the rising edge of the home switch.
5. Operate in the negative direction to find the falling edge of the home switch.
6. Operate in the negative direction to find the Z signal. (not to find Z signal in mode 30)

Homing mode 33
Operate in the negative direction to return to zero, with the home as the Z signal of the motor
Homing mode 34
Operate in the positive direction to return to zero, with the home as the Z signal of the motor
Homing mode 35
Take the current position as the home

If P03.36 is not 0, automatically run the distance of P03.36 after homing.

P03.32 The high speed of homing	Setting range	Unit	Factory default	Related mode		
	10~6000	Rpm (*mm/s)	100	P	S	T

Notes:
The velocity of the homing high-velocity stage.
The linear motor's Unit is mm/s.

P03.33 The low speed of homing	Setting range	Unit	Factory default	Related mode		
	10~6000	Rpm (*mm/s)	10	P	S	T

Notes:
The velocity of the homing low velocity stage.
The linear motor's Unit is mm/s.

P03.34 Time limit of homing	Setting range	Unit	Factory default	Related mode		
	0~1000	ms	10	P	S	T

Notes:
Set the acceleration and deceleration of the homing velocity.

P03.35 Time timeout of homing	Setting range	Unit	Factory default	Related mode		
	1~65535	10ms	50000	P	S	T

Notes:
Homing timeout AL.054, the home resets after shutdown, after need to reset once again the home,

P03.36 Homing offset	Setting range	Unit	Factory default	Related mode		
	-1073807359 ~1073807359	p	0	P	S	T

Notes:
The offset of the operation after homing, with the unit as the encoder unit,

Description of touchprobe function

The function that uses DI8 to capture sensor signals at high velocity for accurate positioning (software version 2.2 or above is compatible with this function)

Related function code:

P03.38 Touchprobe move length	Setting range	Unit	Factory default	Related mode		
	-1073807359 ~1073807359	p	10000	P	S	T

Notes:
The displacement of the probe (DI8) at the probe position after triggering, which is the Unit of the encoder, and the electronic gear ratio has no effect..

P03.3A Touchprobe move speed	Setting range	Unit	Factory default	Related mode		
	0~6000	Rpm (mm/s)	1000	P	S	T

Notes:
The velocity of operation after probe (DI8) is triggered

P03.3B Touchprobe move acceleration and deceleration time	Setting range	Unit	Factory default	Related mode		
	0~60000	ms	100	P	S	T

Notes:
The velocity of operation after probe (DI8) is triggered


P03.3C Configuration of touchprobe	Setting range	Unit	Factory default	Related mode		
	0~0xFFFF	-	0	P	S	T

Notes:

Configuration of probe function:

This setting is as follows:

The function code is set as 16bit



The first bit is the bit for the probe enable/disable, with 0 for disable and 1 for enable;

The second bit is the bit for the probe edge trigger setting, with 0 for rising edge triggering, 1 for falling edge triggering, and 2 for rising edge or falling edge triggering;

The third bit is the bit for the probe mode setting, with 0 for that the probe will automatically return to its original operating state at the end of operation, and 1 for that it will not return to its original operating state until receiving FunIN.20 probe release signal;

The fourth bit is kept at the probe locking time, and the output of FunOut17(ProbeLock) is effective.

For example:

Set to 0x0001 to enable the probe function, and the trigger is effective for the rising edge, which, after the trigger operation is completed, can automatically receive external commands and will also respond to the probe trigger again.

Set to 0x0011 to enable the probe function, and the trigger is effective for the falling edge, which, after the trigger operation is completed, can automatically receive external commands and will also respond to the probe trigger again.

Set to 0x0111 to enable the probe function, and trigger is effective for the falling edge, which will not return to its original operation state until receiving the FunIN.20 probe release signal.

P03.3D Probe filtering time	Setting range	Unit	Factory default	Related mode		
	0~255	25ns	5	P	S	T

Notes:

When the filtering time of probe hardware is amplified, interference can be prevented, but a certain degree of delay will be introduced. If the setting is too small, interference will easily occur and high-precision sensors are required.

It is effective after being powered on again.

Description on Internal Position Function

In general, the internal position is used for internal testing, including: the internal position of 16 segments, of which, the displacement and velocity of each segment's operation, as well as the acceleration and deceleration time, waiting time and operation position attribute thereof, can be set separately.

Related function code:

P10.00 Internal position operation mode	Setting range	Unit	Factory default	Related mode		
	0~1	-	0	P	S	T

Notes:

To run internal commands, it is necessary to set P02.00=1 and P03.00=1; after given a servo enable signal and given FunIN.6(Execute_PP), the operation should be set according to the parameters of Group P10

When P10.00 is set to 0, the single operation ends after triggering the operation.

When P10.00 is set to 1, the operation will proceed circularly after triggering.

P10.03 Selection of number of operation segments	Setting range	Unit	Factory default	Related mode		
	1~16	-	2	P	S	T

Notes:

After triggering the internal position of the operation, it shall operate according to the displacement, velocity and other parameters set by P10.08~P10.77, and the number of operation segments shall be set as required.

(Software version 2.2 and above are compatible with the case of 16 segments)

For example, setting 5 segments:

The set displacement is the user's unit, which is the unit before the electronic gear ratio, and the set velocity unit is rpm (mm/s for linear motor), and the acceleration/deceleration time is the time required for velocity to rise to 1000rpm (mm/s for linear motor).




Fig. 6-13 Schematic Diagram for Operation of Internal Displacement

P10.0E Configuration of Attributes for Segment 1	Setting range	Unit	Factory default	Related mode		
	0~65535	-	0	P	S	T

Notes:

Set to 0, indicating that the displacement of the operation of internal position is an absolute position and must be used after homing or used after determining the U00.07 position.

This Indicates that the set displacement is an absolute position relative to the home or initial position.


Set to 1, indicating that the displacement of the operation of internal position is an incremental position, which means that the operation starts with the current position as the starting point.

Other bits are reserved so that other movement functions can be added later and no need to be set at this time.

The attributes for other segments should be configured in the same way.

6.3 Speed mode

Speedmode related function



Speed related function code

P04.00 Speed command input setting	Setting range	Unit	Factory default	Related mode		
	0~1	-	0	-	S	-

Notes:

0-Digital setting

1- Analog input

The motor rotation is controlled by given velocity command

P04.01 Set velocity number	Setting range	Unit	Factory default	Related mode		
	-6000~6000	rpm(*mm/s)	300	-	S	-

Notes:
Digital set running velocity
Linear motor's unit is mm/S

P04.02 DI jog velocity setting value	Setting range	Unit	Factory default	Related mode		
	-6000~6000	rpm(*mm/s)	300		S	T

Notes:
velocity setting value when using DI jog
Linear motor's unit is mm/s

P04.03 Velocity command acceleration ramp time	Setting range	Unit	Factory default	Related mode		
	0~10000	ms	10	-	S	T

Notes:
Rotary motor: The time for commanding acceleration from 0rpm to 1000rpm
Linear motor: The time for commanding acceleration from 0mm/s to 1000 mm/s.

P04.04 Velocity command deceleration ramp time	Setting range	Unit	Factory default	Related mode		
	0~10000	ms	10	-	S	-

Notes:
Rotary motor: corresponding to the time for commanding deceleration from 1000rpm to 0rpm
Linear motor: is the time time for commanding deceleration from 1000rpm to 0rpm..

P04.06 Jogging velocity acceleration ramp time	Setting range	Unit	Factory default	Related mode		
	0~10000	ms	10	-	S	-

Notes:
Rotary motor: corresponding to the time for commanding deceleration from 1000rpm to 0rpm.
Linear motor: is the time for commanding deceleration from 1000rpm to 0rpm.

P04.07 Velocity corresponding to analog quantity 10V	Setting range	Unit	Factory default	Related mode		
	0~10000	rpm(*mm/s)	3000	-	S	-

Notes:
velocity value corresponding to voltage value when using analog input
Linear motor's unit is mm / S

Velocity acceleration and deceleration time:

The servo driver includes position mode and velocity mode, with the velocity acceleration and deceleration as shown in the figure below: the acceleration time is set as T1, and the deceleration time is T2, which corresponds to the time for acceleration to 1000rpm (*mm/s), so the acceleration is $t_1/1000$, and the deceleration is $t_2/1000$.




Figure 6-14 Description on Acceleration and Deceleration Time

Analog input setting:

P05.30 Analog input offset	Setting range	Unit	Factory default	Related mode		
	-5000~5000	1mv	0	-	S	T

Note:

Modify the velocity (torque) offset corresponding to the analog voltage

P05.31 Analog input filtering	Setting range	Unit	Factory default	Related mode		
	0~60000	0.01ms	200	-	S	T

Notes:

Possible to suppress the "burr" of analog input and improve the "abnormal noise" of operation"

P05.32 Analog input dead zone	Setting range	Unit	Factory default	Related mode		
	0~10000	0.01mv	100	-	S	T

Notes:

When lower than this voltage input, the command is 0

P05.33 Analog input zero drift	Setting range	Unit	Factory default	Related mode		
	0~10000	0.01mv	100	-	S	T

Notes:

It is acceptable to use F09 to set to 1 for automatically adjusting the AI input zero drift




Figure 6-15 Schematic Diagram for Analog Input

Velocity DO output related function code

P06.30 Zero position locked velocity command threshold	Setting range	Unit	Factory default	Related mode		
	0~6000	rpm(*mm/s)	10	P	S	T

Notes:

Set locked threshold value of zero velocity. When the signal FunIn.15(z_Lock) is effective and the command is less than P06.30, the velocity command is 0

Linear motor's velocity unit is mm/s

P06.31 Motor rotation state threshold	Setting range	Unit	Factory default	Related mode		
	0~1000	rpm(*mm/s)	20	P	S	T

Notes:

When the actual velocity of the motor is more than the set value, FunOut.17(VRot) is effective; when the velocity is less than the set value, FunOut.17(VRot) is ineffective.

Linear motor velocity's unit is mm / S

P06.32 Velocity reach signal width	Setting range	Unit	Factory default	Related mode		
	1~200	rpm(*mm/s)	10	P	S	T

Notes:

Meet:

When $|\text{actual torque command} - \text{actual velocity feedback}| \leq \text{P06.32}$, and kept for P06.36 time, the velocity remains at signal FunOut.14(VIn)

Linear motor velocity's Unit is mm/s.

P06.34 Zero velocity output signal threshold	Setting range	Unit	Factory default	Related mode		
	1~6000	rpm(*mm/s)	10	P	S	T

Notes:
 When | motor velocity \leq P06.34 and kept for P06.37, the output of the zero velocity signal FunOut.12(VZero) is effective.
 Linear motor velocity's Unit is mm/s.

P06.35 Velocity DO filtering time	Setting range	Unit	Factory default	Related mode		
	0~6000	rpm(*mm/s)	10	P	S	T

Notes:
 Set the filtering of velocity feedback, and use the filtered velocity feedback to judge the velocity reach signal
 Linear motor velocity's Unit is mm/s.


P06.36 Velocity reach signal hold time	Setting range	Unit	Factory default	Related mode		
	0~1000	ms	0	P	S	T

Notes:
 Meet:
 When | actual torque command-actual velocity feedback \leq P06.32, and kept for P06.36 time, the velocity remains at signal FunOut.14(VIn)

P06.37 Zero velocity signal hold time	Setting range	Unit	Factory default	Related mode		
	0~1000	ms	0	P	S	T

Notes:
 When | motor velocity \leq P06.34, and keep for P06.37 time, the output of the zero velocity signal FunOut.12(VZero) is effective.

6.4 Torque mode



Torque mode related function code

P04.0A Torque command input setting	Setting range	Unit	Factory default	Related mode		
	0~1	-	0	-	-	T

Notes:
Control motor rotation by given torque command
0-digital setting
1-analog input

P04.0B Digital set torque command	Setting range	Unit	Factory default	Related mode		
	-4000~4000	0.1%	0	-	-	T

Notes:
Set digital given torque command (rated current percentage)

P04.0C Torque command corresponding to analog quantity 10V	Setting range	Unit	Factory default	Related mode		
	0~3000	0.1%	0	-	-	T

Notes:
Set digital given torque command (rated current percentage)

P04.0D Torque command acceleration ramp time	Setting range	Unit	Factory default	Related mode		
	0~10000	ms	10	-	-	T

Notes:
Corresponding to the time for commanding increase from 0% torque to 100% torque

P04.0E Torque command deceleration ramp time	Setting range	Unit	Factory default	Related mode		
	0~10000	ms	10	P	S	T

Notes:
Corresponding to the time for commanding decrease from 100% to 0%

P04.0F Emergency stop torque	Setting range	Unit	Factory default	Related mode		
	0~3000	0.1%	1000	P	S	T

Notes:
The value of the emergency stop torque when the emergency stop torque is used for shutdown

P04.10 Velocity positive limit	Setting range	Unit	Factory default	Related mode		
	1~6000	rpm(*mm/s)	3000	P	S	

Notes:
velocity positive limit in velocity position mode enters the velocity mode after reaching the limit value
Linear motor's Unit is mm/s

P04.11 Velocity negative limit	Setting range	Unit	Factory default	Related mode		
	1~6000	rpm(*mm/s)	3000	P	S	

Notes:
velocity reserve limit in velocity position mode enters the velocity mode after reaching the limit value
Linear motor's Unit is mm/s

P04.12 Torque command positive limit	Setting range	Unit	Factory default	Related mode		
	1~4000	0.1%	3000	P	S	T

Note:
Mode torque command positive limit threshold is available

P04.13 Torque command negative limit	Setting range	Unit	Factory default	Related mode		
	1~4000	0.1%	3000	P	S	T

Notes:
Mode torque command negative limit threshold is available

P04.14 Torque mode velocity positive limit	Setting range	Unit	Factory default	Related mode		
	1~6000	rpm(*mm/s)	3000	-	-	T

Notes:
velocity positive limit in torque mode enters the velocity mode after reaching the limit value
Linear motor's Unit is mm/s

P04.15 Torque mode velocity negative limit	Setting range	Unit	Factory default	Related mode		
	1~6000	rpm(*mm/s)	3000	-	-	T

Notes:
velocity negative limit in torque mode enters the velocity mode after reaching the limit value
Linear motor's Unit is mm/s

Torque DO output related function code

P06.3A Torque reach reference value	Setting range	Unit	Factory default	Related mode		
	0~3000	0.1%	0	P	S	T

Notes:

Set the reference threshold of torque reach output

P06.3B Torque reach signal's effective threshold	Setting range	Unit	Factory default	Related mode		
	0~3000	0.1%	0	P	S	T

Notes:

Meet:

When $-P06.3B \leq \text{actual torque command} - P06.3A \leq P06.3B$, the torque reach signal is effectively output

P06.3C Torque reach signal's ineffective threshold	Setting range	Unit	Factory default	Related mode		
	0~3000	0.1%	0	P	S	T

Notes:

Meet:

When actual torque command $-P06.3A \geq P06.3C$ or
Actual torque command $-P06.3A \geq -P06.3C$,
Torque reach signal is ineffective

Torque reach signal FunOut.16

6.5 Mode switch

When P02.00=3, it is acceptable to use DI to switch operating modes as shown in the table below

ModSel1 (FunIn.11)	ModSel2 (FunIn.12)	Mode
0	0	Position mode
0	1	Torque mode
1	0	Speed mode
1	1	Position mode


When the DI terminal is used for mode switching, only two modes are normally used for switching. The host device can only select and control one DI function, and the other DI function can be set as effective or ineffective by default.

Chapter 7 Adjustment


7.1 Gain adjustment target

Gain adjustment is for the purpose to allow the motor to work without delay according to the command from of the upper computer, which can give full play to the mechanical performance. Users often need to adjust the relative gains of position loop and velocity loop.


Here are some common commissioning waveforms



Due to the weak gain adjustment, the servo system has a slow response and a long tail




The gain matching between the position loop and the speed loop is unreasonable, resulting in overshoot.



The gain of position loop or speed loop is too strong, resulting in oscillation.


The ideal position response can be achieved by enhancing the gain of position loop and speed loop, as well as feedforward and other parameters.



In the actual commissioning process, due to the influence of mechanical factors, the position feedback is difficult to completely coincide with the instruction. At this time, it is only necessary to ensure that the response has no overshoot or oscillation and the positioning time is less than the required value.


7.2 Manual gain adjustment

Gain adjustment often follows the following process



7.2.1 Inertia identification

Inertia identification is the first step for parameter adjustment, which can be identified by panel or background. If it is identified by background, it can be identified by wizard. If it is operated by panel, the operation process is as follows:



Schematic diagram for inertia identification

Inertia identification related function code

F01 Automatic identification of load inertia ratio	Setting range	Unit	Factory default	Related mode		
	-	-	-	P	S	T

Notes:

Auxiliary function manual automatic identification of inertia ratio

P00.0A Load inertia ratio	Setting range	Unit	Factory default	Related mode		
	0~12000	-	1.00	P	S	T

Notes:

Load inertia ratio = external load inertia / motor load inertia

P0A.00 Inertia identification operation track	Setting range	Unit	Factory default	Related mode		
	0~1	-	0	P	S	T

Notes:

0- positive and negative triangle command (limited mechanical stroke, positive and negative motor operation)

1-Jog mode (unlimited mechanical stroke, motor running in one direction)

7.2.2 Rigidity grade adjustment

When setting the initial parameters, you can select the self-adjusting mode, that is, P00.00 is set as a non-0 parameter, which is used to set the gain parameters by groups, and then set P00.01, which is used to gradually strengthen the servo response. The function codes affected by different modes of Pn00.00 are as follows:

Function code	Description	Rigid table mode	Positioning mode	one-parameter mode
P00.02	Group 1 speed loop gain	○	○	○
P00.03	Group 1 speed loop integration time constant	○	○	○
P00.04	Group 1 position loop gain	○	○	○
P00.05	Group 1 torque filtering constant	○	○	○
P00.06	Group 2 speed loop gain	×	○	×
P00.07	Group 2 speed loop integration time constant	×	○	×
P00.08	Group 2 position loop gain	×	○	×
P00.09	Group 2 torque filtering constant	×	○	×
P00.10	speed feed-positive gain	×	○	○
P00.12	PDF control factor	×	×	○
P00.19	Gain switching mode	×	○	×

Gain setting related function code

P00.00 Self adjusting mode selection	Setting range	Unit	Factory default	Related mode		
	0~3	-	0	P	S	T

Notes:

0-manual gain setting

1-rigid table mode

2-positioning mode

3-single parameter mode

According to the load and operation mode, different adjustment methods are selected to give full play to the best responsiveness and stability of the system.

P00.01 Rigidity grade selection	Setting range	Unit	Factory default	Related mode		
	1~31	-	0	P	S	T

Note:

The higher the rigidity is, the better the responsiveness of the system is. However, the higher the rigidity is, the system will vibrate, which should be set according to the actual situation

P00.02 Group 1 speed loop gain	Setting range	Unit	Factory default	Related mode		
	1~20000	0.1HZ	250	P	S	T

Notes:

The larger the velocity loop proportional gain setting is, the faster the velocity loop response is, which, however, is easy to cause system oscillation if it is too large

P00.03 Group 1 speed loop integration time constant	Setting range	Unit	Factory default	Related mode		
	15~51200	0.01ms	3183	P	S	T

Notes:

The larger the velocity loop integration time constant proportional gain setting is, the smaller the velocity loop integration effect is..

P00.04 Group 1 position loop gain	Setting range	Unit	Factory default	Related mode		
	0~20000	0.1HZ	400	P	S	T

Notes:

Position loop proportional gain

P00.05 Group 1 torque filtering constants	Setting range	Unit	Factory default	Related mode		
	0~3000	0.01ms	79	P	S	T

Notes:

velocity loop low pass filtering time

P00.06 Group 2 speed loop gain	Setting range	Unit	Factory default	Related mode		
	1~20000	0.1HZ	250	P	S	T

Notes:

The larger the velocity loop proportional gain setting is, the faster the velocity loop response is, which, however, is easy to cause system oscillation if it is too large

P00.07 Group 2 speed loop integration time constants	Setting range	Unit	Factory default	Related mode		
	15~51200	0.01ms	3183	P	S	T

Notes:

The larger the velocity loop integration time constant proportional gain setting is, the smaller the velocity loop integration effect is.

P00.08 Group 2 position loop gain	Setting range	Unit	Factory default	Related mode		
	0~20000	0.1HZ	400	P	S	T

Notes:

Position loop proportional gain

P00.09 Group 2 torque filtering constant	Setting range	Unit	Factory default	Related mode		
	0~3000	0.01ms	79	P	S	T

Notes:

velocity loop low pass filter time

P00.10 Speed feedforward gain	Setting range	Unit	Factory default	Related mode		
	0~1000	0.01%	0	P	S	-

Notes:

Used to set the position lead compensation

P00.12 PDFF control factor	Setting range	Unit	Factory default	Related mode		
	0~1000	0.01%	1000	P	S	T

Notes:

Suppression velocity loop overshoot factor

P00.19 Gain switching mode	Setting range	Unit	Factory default	Related mode		
	0~4	0-	0	P	S	T

Notes:

Set the first group of gain parameters and the second group of gain parameters switching method

When setting different rigidity grade P00.0, the loop gain corresponding to different grades is shown in the table below:


Rigidity grade	Group 1 gain				Group 2 gain			
	P00.02	P00.03	P00.04	P00.05	P00.06	P00.07	P00.08	P00.09
	First position loop gain (0.1/s)	First speed loop gain (0.1HZ)	First speedloop integration time constant (0.1ms)	First torque filtering time constant (0.01ms)	Second position loop gain (0.1/s)	Second speed loop gain (0.1HZ)	Second speedloop integration time constant (0.1ms)	Second torque filtering time constant (0.01ms)
0	20	15	3700	1500	25	15	51200	1500
1	25	20	2800	1100	30	20	51200	1100
2	30	25	2200	900	40	25	51200	900
3	40	30	1900	800	45	30	51200	800
4	45	35	1600	600	55	35	51200	600
5	55	45	1200	500	70	45	51200	500
6	75	60	900	400	95	60	51200	400
7	95	75	700	300	120	75	51200	300
8	115	90	600	300	140	90	51200	300
9	140	110	500	200	175	110	51200	200
10	175	140	400	200	220	140	51200	200
11	320	180	310	126	380	180	51200	126
12	390	220	250	103	460	220	51200	103
13	480	270	210	84	570	270	51200	84
14	630	350	160	65	730	350	51200	65
15	720	400	140	57	840	400	51200	57
16	900	500	120	45	1050	500	51200	45
17	1080	600	110	38	1260	600	51200	38
18	1350	750	90	30	1570	750	51200	30
19	1620	900	80	25	1880	900	51200	25
20	2060	1150	70	20	2410	1150	51200	20
21	2510	1400	60	16	2930	1400	51200	16
22	3050	1700	50	13	3560	1700	51200	13
23	3770	2100	40	11	4400	2100	51200	11
24	4490	2500	40	9	5240	2500	51200	9
25	5000	2800	35	8	5900	2800	51200	8
26	5600	3100	30	7	6500	3100	51200	7
27	6100	3400	30	7	7100	3400	51200	7
28	6600	3700	25	6	7700	3700	51200	6
29	7200	4000	25	6	8400	4000	51200	6
30	8100	4500	20	5	9400	4500	51200	5
31	9000	5000	20	5	10500	5000	51200	5

The factory rigidity level is generally 12 by default

7.2.3 Vibration suppression setting

7.2.3.1 Set resonant frequency manually.

Under the condition that the servo parameters continuously strengthen the gain, the connection rigidity of the mechanical system may be insufficient, so mechanical resonance may occur, and the vibration frequency may be different, some are high-frequency vibration, some are low-frequency vibration, so it is necessary to set a notch filter at the resonance frequency to suppress the mechanical resonance of the system. The amplitude characteristics of the system at high frequency resonance are as follows:



Servo provides 4 sets of trap parameters for resonance point suppression. Each set of trap can be set with resonance point, anti-resonance point, trap width, trap depth and the corresponding meaning of the parameters as shown in the above figure. When obtaining mechanical resonance point, there are usually two methods. One is to observe its vibration period through the background torque command waveform, and then obtain it through $f_0 = 1/T$ calculation, or obtain the mechanical resonance frequency through the background frequency sweeping function. Each trap set function code is as follows:

P01.04 Group 1 notch filter anti-resonance frequency	Setting range	Unit	Factory default	Related mode		
	10~5000	HZ	5000	P	S	T

Notes:
Corresponding system anti-resonance point

P01.05 Group 1 notch frequency	Setting range	Unit	Factory default	Related mode		
	50~5000	HZ	5000	P	S	T

Notes:
Corresponding system resonance point

P01.06 Group 1 notch filter Band width	Setting range	Unit	Factory default	Related mode		
	0~9	-	2	P	S	T

Notes:
Determine the frequency range for system suppression

P01.07 Group 1 notch filter attenuation level	Setting range	Unit	Factory default	Related mode		
	0~99	-	0	P	S	T

Notes:
Determine the suppression depth to the resonance point of the system

P01.08 Group 2 notch filter anti-resonance frequency	Setting range	Unit	Factory default	Related mode		
	10~5000	HZ	5000	P	S	T

Note:
Corresponding system anti resonance point

P01.09 Group 2 notch filter frequency	Setting range	Unit	Factory default	Related mode		
	50~5000	HZ	5000	P	S	T

Notes:
Corresponding system resonance point

P01.0A Group 2 notch filter band width	Setting range	Unit	Factory default	Related mode		
	0~9	-	2	P	S	T

Notes:
Determine the frequency range of system suppression

P01.0B Group 2 notch filter attenuation level	Setting range	Unit	Factory default	Related mode		
	0~99	-	0	P	S	T

Notes:
Determine that depth of suppression to the resonance point of the system

P01.0C Group 3 notch filter anti-resonance frequency	Setting range	Unit	Factory default	Related mode		
	10~5000	HZ	5000	P	S	T

Notes:
Corresponding system anti resonance point

P01.0D Group 3 notch filter frequency	Setting range	Unit	Factory default	Related mode		
	50~5000	HZ	5000	P	S	T

Note:
Corresponding system resonance point

P01.0E Group notch filter band width	Setting range	Unit	Factory default	Related mode		
	0~9	-	2	P	S	T

Note:
Determine the frequency range of system suppression

P01.0F Group 3 notch filter attenuation level	Setting range	Unit	Factory default	Related mode		
	0~99	-	0	P	S	T

Note:
Determine that depth of suppression to the resonance point of the system

P01.10 Group 4 notch filter anti-resonance frequency	Setting range	Unit	Factory default	Related mode		
	10~5000	HZ	5000	P	S	T

Notes:
Corresponding system anti resonance point

P01.11 Group 4 notch filter frequency	Setting range	Unit	Factory default	Related mode		
	50~5000	HZ	5000	P	S	T

Notes:
Corresponding system resonance point

P01.12 Group 4 notch filter band width	Setting range	Unit	Factory default	Related mode		
	0~9	-	2	P	S	T

Notes:
Determine the frequency range for system suppression

P01.13 Group 4 notch filter attenuation level	Setting range	Unit	Factory default	Related mode		
	0~99	-	0	P	S	T

Notes:
Determine that depth of suppression to the resonance point of the system

In the meaning of the above function codes, the width is defined as shown in the following table

Width setting	Actual suppression width of notch filter
0	$0.5 * f_0$
1	$0.6 * f_0$
2	$0.7 * f_0$
3	$0.8 * f_0$
4	f_0
5	$1.2 * f_0$
6	$1.4 * f_0$
7	$1.6 * f_0$
8	$1.8 * f_0$
9	$2 * f_0$

Depth definition represents the ratio of input and output of resonance frequency points. The smaller the value, the greater the suppression depth. The larger the value, the shallower the suppression depth, and the output amplitude/input amplitude = depth level/100.

The smaller the depth value is set, the deeper the notch depth is.

7.2.3.2 Automatically set resonance frequency

If you don't want to set the function code manually to suppress resonance, you can turn on the adaptive filter to suppress resonance frequency. This function can automatically set the parameters of the third group and the fourth group of notch filters. When no resonance point is found after turning on, it will automatically exit 30 minutes later. If the resonance point is found and the notch filter is set, the vibration will become more intense, and it will also self The adaptive function is exited and the parameters of the notch filter are reset.

The adaptive related function codes are as follows:

P01.00 Adaptive filter mode selection	Setting range	Unit	Factory default	Related mode		
	0~4	-	0	P	S	T

Notes:

- 0- does not turn on the adaptive filter
- 1- Group 3 notch filter parameters automatically updated
- 2- Automatic update of notch filter parameters for groups 3 and 4
- 3- Test resonance frequency only, shown in P01.02
- 4- Clear the values of trap filters in groups 3 and 4

P01.01 Vibration determination threshold	Setting range	Unit	Factory default	Related mode		
	0~1000	0.1%	20	P	S	T


Note:
100% corresponds to the threshold value of motor rated torque to judge system oscillation

P01.02 Resonance frequency identification results	Setting range	Unit	Factory default	Related mode		
	0~5000	HZ	-	P	S	T


Notes:
Displays the tested resonant frequency value

7.2.3.3 Low frequency jitter suppression

In some flexible loads such as mechanical hands, when the motor running tracking command reaches a given position, the load will overshoot due to the non-rigid connection of the load, thus driving the motor to overshoot, resulting in low-frequency jitter, as shown in the following figure:



At this time, the jitter can be suppressed by setting the low-frequency vibration frequency. The filter directly acts on the position command, as follows:



The low frequency filter related function codes are as follows:

P01.0F Low frequency vibration suppression mode	Setting range	Unit	Factory default	Related mode		
	0~1	-	0	P	-	-

Notes:

0-set the low frequency suppression filter manually

1-set the low frequency suppression filter automatically

P01.20 Low frequency vibration determination threshold	Setting range	Unit	Factory default	Related mode		
	0~65535	-	10	P	-	-

Notes:

When the position deviation is greater than the set value, it is considered that low frequency vibration occurs

P01.21 Low frequency vibration frequency	Setting range	Unit	Factory default	Related mode		
	10~1000	0.1HZ	1000	P	-	-

Notes:

Measured low-frequency vibration frequency

P01.22 Low-frequency vibration filter setting	Setting range	Unit	Factory default	Related mode		
	0~10	-	2	P	-	-

Notes:

The larger the value, the larger the filter width, but the greater the delay

P01.23 Low-frequency resonance frequency attenuation ratio	Setting range	Unit	Factory default	Related mode		
	12~30	0.1	12	P	-	-

Note:

The larger the value is, the greater the filtering depth is, and the smaller the position command delay is

7.2.3.4 Full closed loop vibration suppression

In the full closed-loop system, the servo system controls the velocity through the motor encoder and the position through the encoder on the load. Due to the torque between the motor and the load, the velocity fed back by the two encoders is not synchronous, which shows that there is shaking at the load end. In order to suppress the vibration caused by the asynchronous, the following parameter settings can be used to suppress it.

P08.04 Hybrid vibration suppression gain	Setting range	Unit	Factory default	Related mode		
	-3000~3000	0.1HZ	0	P	-	-

Note:

Used to adjust the vibration suppression rate and has obvious effect when the torque of motor and load is large

P08.05 Cut-off frequency of hybrid vibration suppression filter	Setting range	Unit	Factory default	Related mode		
	10~5000	1HZ	500	P	-	-

Note:

Vibration suppression filter setting

P08.06 Full closed loop velocity correction coefficient	Setting range	Unit	Factory default	Related mode		
	0~1000	0.1%	500	P	-	-

Notes:

Put the velocity feedback compensation of the encoder at the load end into the actual velocity control loop

P08.07 Filter coefficient of internal and external ring position deviation	Setting range	Unit	Factory default	Related mode		
	0~1000	0.1ms	0	P	-	-

Notes:

Filter the position feedback of load end and motor end


7.2.4 Practical application gain adjustment

7.2.4.1 Feedpositive function

In the position control, the velocity command generated in the next cycle can be estimated by the position command, which can be directly compensated to the velocity control loop, avoiding the role of the position regulator, and effectively reducing the position deviation in the position control.

Similarly, in the velocity control, the torque command generated in the next cycle can be directly compensated to the current control loop through the velocity command estimation, which can effectively improve the velocity control response.

The control loop is as follows:



The function codes used for commissioning are as follows:

P00.0F Velocity control feedpositive selection	Setting range	Unit	Factory default	Related mode		
	0~2	-	1	P	S	-

Notes:

- 0~ no velocity feed positive
- 1~ internal velocity feedpositive
- 2~ external velocity feedpositive

P00.10 Velocity feedpositive gain	Setting range	Unit	Factory default	Related mode		
	0~1000	0.1%	0	P	-	-

Notes:

Only the position mode is effective, the larger the velocity feedpositive is, the better the follow command is, the smaller the position deviation is, but the larger the feedpositive is, the system overshoot is easily caused, which should be set according to the actual situation

P00.11 Velocity feedpositive filter time parameter	Setting range	Unit	Factory default	Related mode		
	0~6400	0.01ms	50	P	-	-

Notes:

Low pass filter is used for velocity feedpositive to avoid too drastic change of velocity feedpositive

P00.14 Torque feedpositive gain	Setting range	Unit	Factory default	Related mode		
	0~1000	0.1%	0	P	S	-

Notes:

The larger the torque feedpositive is, the better the follow-up velocity command is, but the larger the feedpositive is, the system will be overshoot, the stability will be poor, and the abnormal noise will be set according to the actual situation

P00.15 Torque feedpositive filtering time parameter	Setting range	Unit	Factory default	Related mode		
	0~6400	0.01ms	0	P	S	-

Notes:
The low-pass filter is applied to the torque feedpositive to avoid the drastic change of velocity feedpositive

7.2.4.2 Gain switching


When the servo is running and stopping, it is often necessary for the servo to have different response characteristics, namely:

Low gain is required to stop to avoid zero position vibration

High gain is required at stop to improve servo locking capability

High gain is needed in operation to improve servo tracking capability

In order to meet the requirements of operation and stop at the same time, the gain switching function needs to be introduced, as shown in the following figure:



The gain switching function mainly switches between the first group of gain and the second group of gain. In addition to the gain,

The function codes used are shown in the table below:

P00.19 Gain switching mode selection	Setting range	Unit	Factory default	Related mode		
	0~4	-	0	P	-	-

Notes:

0 ~ fixed as the first group gain

1 ~ maintain the first group of gain, and the di switching integral time is 0

2 ~ use DI to switch the first and second group gains

3 ~ use position command + velocity feedback to switch

4 ~ use position command + velocity feedback to switch to lock the gain

P00.1A Gain switching delay time	Setting range	Unit	Factory default	Related mode		
	0~10000	0.1ms	50	P	-	-

Notes:
Used to set the delay time for switching from the second gain to the first gain

P00.1B Gain switching level	Setting range	Unit	Factory default	Related mode		
	0~20000	0.1ms	50	P	-	-

Notes:
If the switching condition is position, then the unit is p; if the switching condition is velocity, then the unit is RPM (* mm/s); if the switching condition is torque, then the unit is 0.1%

P00.1C Gain switching delay	Setting range	Unit	Factory default	Related mode		
	0~20000	0.1ms	50	P	-	-

Notes:
If the switching condition is position, then the unit is p; if the switching condition is velocity, then the unit is RPM (* mm/s); if the switching condition is torque, then the unit is 0.1%

P00.1D Gain switching time	Setting range	Unit	Factory default	Related mode		
	0~10000	0.1%	30	P	-	-

Notes:
Used to set the time for switching from the first gain to the second gain


P00.0E Group 3 gain coefficient	Setting range	Unit	Factory default	Related mode		
	50~10000	1%	30	P	-	-

Notes:
Used to set the amplification factor of the third group of gain and the first group of gain when stopping, and only amplify the position proportional gain and the velocity proportional gain


P00.0F Group 3 gain hold times	Setting range	Unit	Factory default	Related mode		
	0~10000		0	P	-	-

Notes:
Used to set the group 3 gain holding time when stopping

When the gain switching mode is selected as 3, the switching process is as follows:




When the switching mode is selected as 4, a new group gain is introduced on the basis of 3. The group 3 gain amplification coefficient P00.0E is only for the position proportional gain and velocity proportional gain of the group 1 gain, and the velocity integration time and torque filtering coefficient remain the same as group 1, with the switching process as follows:




7.2.4.3 Command filtering function

In the position control, if the host device sends commands with a fast frequency, which exceeds the overload capacity of the servo motor; or if the upper computer's commands have a large jump, resulting in obvious starting impact sound of the servo motor, the position commands need to be filtered to make the servo start smooth, reduce the impact on the load, and reduce the servo load rate.


For the smooth filtering of the position command, when the filtering time is set, the position command changes as follows:



For the low-pass filtering of the position command, when the filtering time is set, the command will obviously decrease when accelerating to the highest velocity and decelerating to the lowest velocity, as shown below:



For model position command filtering, the filtering effect of position command can be increased or decreased by adjusting the model gain after the model loop is opened. Its effect on position command is similar to that of low-pass filtering. The smaller the model gain, the stronger the filtering effect, while the larger the model gain, the weaker the filtering effect.



The function codes related to position command are as follows:

P00.25 Model loop enable	Setting range	Unit	Factory default	Related mode		
	0~1	-	0	P	-	-

Notes:

0 ~ disable model loop

1 ~ enable model loop

P00.26 Model loop gain	Setting range	Unit	Factory default	Related mode		
	1~20000	0.1HZ	400	P	-	-

Notes:

The larger the gain, the higher the model loop response and the smaller the position instruction delay

7.2.4.4 Disturbance suppression of external forces

(1) Disturbance observer

When the servo motor is running, if the load is suddenly affected by external force, the velocity fluctuation of the servo motor may occur, resulting in mechanical noise or vibration. In order to suppress the impact of this load fluctuation and reduce the velocity fluctuation, the observer can be interfered. The adjustment function code is as follows:

P00.26 Model loop gain	Setting range	Unit	Factory default	Related mode		
	1~20000	0.1HZ	400	P	-	-

Notes:

The larger the gain, the higher the model loop response and the smaller the position command delay

P01.1A Disturbance torque compensation gain	Setting range	Unit	Factory default	Related mode		
	0~1000	0.1%	0	P	S	-

Notes:

The larger the setting value is, the stronger the disturbance suppression effect will be, but high frequency noise may occur if it is too large. In this case, commissioning shall be carried out in coordination with the filtering time

P01.1B Disturbance torque filtering time	Setting range	Unit	Factory default	Related mode		
	0~2500	0.01ms	50	P	S	-

Notes:

When reducing the noise produced by disturbance suppression, the larger the time is, the stronger the filtering effect will be, but it will slow down the suppression velocity

(2) Instantaneous velocity observation and velocity filtering

When the resolution of the motor encoder is low, if the loop gain is increased, strong noise may occur, even mechanical vibration may occur when the zero position is fixed. In order to suppress this noise, it is necessary to deal with the velocity feedback to reduce the velocity fluctuation.

P00.20 Average filtering time of velocity feedback	Setting range	Unit	Factory default	Related mode		
	0~5	-	0	P	S	T

Notes:

0 ~ no smooth filtering

1 ~ 2 times smooth filtering

2~4 times smooth filtering

3~8 times smooth filtering

4 ~ 16 times smooth filtering

5 ~ 32 times smooth filtering

P00.21 Cut-off frequency of velocity feedback low-pass filter	Setting range	Unit	Factory default	Related mode		
	50~5000	HZ	5000	P	S	T

Note:

When it is set to 5000, there is no filtering effect. The smaller the setting value is, the stronger the filtering effect is

P00.22 Cut-off frequency of torque observation	Setting range	Unit	Factory default	Related mode		
	1~5000	HZ	400	P	S	-

Note:

Used to filter the observed torque value. The larger the value, the smaller the delay

P00.23 Torque observation proportional gain	Setting range	Unit	Factory default	Related mode		
	1~8000	HZ	400	P	S	-

Note:

As for the observed proportional gain, the larger the value is, the smaller the delay is

P00.24 Velocity observation position compensation gain	Setting range	Unit	Factory default	Related mode		
	0~3000	HZ	400	P	S	-


Notes:

Used to compensate the velocity deviation caused by the position observation deviation

(2) Friction compensation

Friction compensation is used to solve the problem of starting delay caused by friction. After friction compensation is added, the servo motor can be started quickly

and the starting position deviation can be reduced. The compensation method is as follows:



Relevant function codes are set as follows:

P01.1C Constant torque compensation value	Setting range	Unit	Factory default	Related mode		
	-1000~1000	0.1%	0	P	S	-

Notes:

Compensation for external constant load forces such as gravity

P01.1D positive friction compensation	Setting range	Unit	Factory default	Related mode		
	-1000~1000	0.1%	0	P	S	-

Note:

positive rotation compensation value

P01.1E Negative friction compensation	Setting range	Unit	Factory default	Related mode		
	-1000~1000	0.1%	0	P	S	-

Note:

negative rotation compensation value

Chapter 8 Communication Mechanism

This servo driver is compatible with the serial communication function of RS-485 and RS-232. The parameters in the servo system can be accessed and changed by using the communication function. RS-485 and RS-232 communication functions can be used at the same time.

RS485 interface is located in CN1, for its wiring, see Chapter 3.2.5;

RS232 is CN2. For its wiring, see Chapter 3.3. You can use the commercially available USB mini-B to connect the PC.

Modbus related function settings :

P09.00 Station number selection	Setting range	Unit	Factory default	Related mode		
	0~127	1	0	P	S	T

Notes:

When RS-232 / RS-485 communication is used, only one station number can be set for a group of servo drivers.

If the station number is set repeatedly, normal communication will not be possible

P09.01 Modbus communication baud rate communication setting	Setting range	Unit	Factory default	Related mode		
	0~6	-	6	P	S	T

Notes:

0-2400 Kbp/s

1-4800 Kbp/s

2-9600 Kbp/s

3-19200 Kbp/s

4-38400 Kbp/s

5-57600 Kbp/s

6-115200 Kbp/s

P09.02 Modbus communication data format	Setting range	Unit	Factory default	Related mode		
	0~3	-	0	P	S	T

Notes:

To be compatible with the communication format of the upper computer

0-no check, 2 stop bits

1-even check, 1 stop bit

2-odd check, 1 stop bit

3-no check, 1 stop bit

P09.0a Background software 232 baud rate communication setting	Setting range	Unit	Factory default	Related mode		
	0~6	-	6	P	S	T

Notes:
0-2400 Kbp/s
1-4800 Kbp/s
2-9600 Kbp/s
3-19200 Kbp/s
4-38400 Kbp/s
5-57600 Kbp/s
6-115200 Kbp/s

P09.10485 EEROPM save prohibited during communication	Setting range	Unit	Factory default	Related mode		
	0~1	-	0	P	S	T

Notes:
0~ enables EEPROM save
1~ disable EERPOM save
Since EERPOM save is limited in number of times, it is better to set this parameter to 1 when frequently reading and writing parameters (function codes) in communication.
If you do not read and write frequently, you do not need to change. The setting of this parameter does not affect the setting of the panel.

8.1 Mod bus communication protocol

RTU (Remote Terminal Unit) mode generally begins with one static signal and ends with another static signal, and between which, there are communication positions, function codes, data contents, CRC (Cyclical RedundancyCheck), etc.

RTU mode: :

start	Static time over 10ms
Slave Address	Communication address : 1-byte
Function	Function code : 1-byte
Data (0)	Data content : n-word =2n-byte , n<=10
.....	
Data (n-1)	
CRC	Error check : 1-byte
End	Static time over 10ms

8.2 RTU function command

Function : 0x03 read function code

For example, the station number is 1 and the read function code is P04.10

Information sent from the master station:

Start	Static time over 10ms
Slave Address	Station number : 0x01
Function	Function : 0x03
Data (0)	Beginning address group number : 0x04
Data (1)	Beginning address offset: 0x10
Data (2) (word)	The high bit of the number of read function codes: 0x00
Data (3) (word)	The lower bit of the number of read function codes: 0x01
CRC Check Low	0x84
CRC Check High	0xFF
End	Static time over 10ms

Information returning from the master station :

Start	Static time over 10ms
Slave Address	Station number : 0x01
Function	function : 0x03
Number of data(byte)	Data : 0x02
Data (0)	The high byte of beginning data: 0x17
Data (1)	The low byte of beginning data: 0x17
CRC Check Low	0xB6
CRC Check High	0x50
End	Static time over 10ms

That is, the transmit frame is: 01 03 04 10 00 01 84 FF

The response is: 01 03 02 17 70 B6 50

Function : 0x06 write function code

For example, if the station number is 1 and the value of writing a 16 bit function code p02.19 is 300, this function cannot write a 32-bit function code.

Information sent from the master station:

Start	Static time over 10ms
Slave Address	Station number:0x01
Function	Function:0x06
Data (0)	Address group number::0x02
Data (1)	Address offset:0x19
Data (2)	The high bit of the value of write function code:0x01
Data (3)	The low bit of the value of write function code:0x2C
CRC Check Low	0x59
CRC Check High	0xF8
End	Static time over 10ms

Information returning form the slave station:

Start	Static time over 10ms
Slave Address	Station number:0x01
Function	Function:0x06
Data (0)	Address group number::0x02
Data (1)	Address offset:0x19
Data (2)	The high bit of the value of written function code:0x01
Data (3)	The low bit of the value of written function code:0x2C
CRC Check Low	0x59
CRC Check High	0xF8
End	Static time over 10ms

That is, the transmit frame is:01 06 02 19 01 2C 59 F8

The response is:01 06 02 19 01 2C 59 F8

Function : 0x10 Write 32-bit function code

For example, if the station number is 1 and the value of 32-bit function code p03.12 is 1048576, this function cannot write 16 bit function code

Start	Static time over 10ms
Slave Address	Station number:0x01
Function	Function:0x10
Data (0)	Address group number::0x03
Data (1)	Address offset:0x12
Data (2)	The high bit of the number (word) of write function cod:0x00
Data (3)	The low bit of the number (word) of write function code:0x02
Data (4)	The lower bit of the number of write bytes (word):0x04
Data (5)	The values of function codes bit8~bit15 , 0x00
Data (6)	The values of function codes bit0~bit7 0x00
Data (7)	The values of function codes bit24~bit31 0x00
Data (8)	The values of function codes bit16~bit23 0x10
CRC Check Low	0x66
CRC Check High	0x46
End	Static time over 10ms

Information returning from the slave station:

Start	Static time over 10ms
Slave Address	Station number:0x01
Function	Function:0x10
Data (0)	Address group number::0x03
Data (1)	Address offset:0x12
Data (2)	High bit of the number of written function code:0x00
Data (3)	Low bit of the number of written function code:0x02
CRC Check Low	0xE1
CRC Check High	0x89
End	Static time over 10ms

That is, the transmit frame is:01 10 03 12 00 02 0400 00 00 10 66 46

The response is:01 10 03 12 00 02 E1 89

8.3 Mod bus function code communication address

1. Set the function code to Pxx.YY and the corresponding modbus address to xx.yy, with, for example, P05.10 0x05 as the group number and 0x10 as the offset, which are both in hexadecimal format.

2. The corresponding communication address of observation group function code (this group is read-only) is:

U00.YY: The corresponding mod bus address: Group number is 0x20, address offset is 0xYY. For example, read the current temperature U00.1D of the driver, with the address as 0x20 and offset as 0x1D.

U01.YY: Corresponding modbus address: The group number is 0x21 and the address offset is 0xYY. For example, when reading the selected fault, the rotating velocity is U01.05, with the address as 0x21 and the offset as 0x05.

U02.YY: Corresponding modbus address: the group number is 0x22, with address offset of 0xYY,. For example, in case of software version U02.00, the address is 0x22, and the offset is 0x00.

3. The corresponding communication address of the auxiliary function code group is:

FYY.: Corresponding modbus address: The group number is 0x25, with address offset as 0xYY.

Chapter 9 Alarm Treatment

List of alarm messages

Alarm code	Alarm name	Alarm type	Mechanism and Treatment measures
AL.00.0	FPGA parallel port error	Non-resettable error	Power on again. If the alarm still occurs, please replace it with a new one
AL.00.1	Abnormal system parameters	Non-resettable error	Check the address of abnormal parameter function code of U00.3e and U00.3f, and if it indicates that this function range exceeds the limit value, please contact our personnel for changes.
AL.00.2	Abnormal function code parameter	Non-resettable error	Use F04 to reset the function code
AL.00.3	Abnormal manufacturer's parameters	Non-resettable error	Use F04 to reset the function code
AL.00.7	Incompatible software versions	Non-resettable error	Please contact our personnel
AL.01.0	Overvoltage	Resettable error	Ensure that the 220v input is within the range of (200V~240v) and an alarm is given for overvoltage during operation. Set the release function and add an external release resistor to release excess energy or increase the acceleration and deceleration time.
AL.01.1	Under-voltage	Resettable error	Check whether the external power supply input is too low to ensure that the 220v input is within the range of 200V~240V
AL.01.3	Loss of phase in power supply	Resettable error	Test whether there is a loss of phase in the external power input, or it is acceptable to use P07.05=2 to shield this fault.
AL.01.5	Phase sequence error	Resettable error	UVW wiring error, need to change over the wiring of any two phases
AL.02.0	Over-current occurring in phase p of the bus.	Non-resettable error	Test the UVW wiring for a short and the resistor between the UVW phases for the correct resistance value
AL.02.1	Over-current occurring in phase	Non-resettable error	The resistance value of the brake resistor is too small or there is a short

	n of the bus.		circuit
AL.02.2	Overcurrent fault in phase U	Non-resettable error	There is an error of short-circuit to ground or UVW is short circuited to PE
AL.02.3	Overcurrent fault in phase A	Non-resettable error	Parameter setting error leading to excessive gain, it is necessary to properly reduce the rigidity and gain
AL.02.4	Short circuit to ground	Non-resettable error	Ensure that the insulation between U, V, W and preaches the level of M Ω
AL.02.5	Release overcurrent	Non-resettable error	The brake resistor is short circuited; check the resistance value of the brake resistor
AL.02.6	Abnormal PWM signal	Non-resettable error	Excessive velocity fluctuation and gain If the current loop gain is too large, reduce the motor current loop gains P18.14 and P18.15.
AL.02.7	Excessive drive temperature	Resettable error	Increase space heat dissipation and reduce average load rate
AL.02.8	Driver overload	Resettable error	Reduce the average load rate, increase the acceleration and deceleration time, and detect whether there is mechanical jamming.
AL.02.9	Motor overload	Resettable error	Reduce the average load rate, increase the acceleration and deceleration time, detect whether there is mechanical jamming, and appropriately increase and adjust P07.11. It is also acceptable to adjust P07.01 to 1 so as to turn off the overload error of the motor.
AL.02.A	Motor stalling	Resettable error	Test if there is mechanical jamming Test if there is wrong UVW wiring If case of an electrical angle error, use Fn03 to re-identify the electrical angle.
AL.02.B	Excessive Ptc motor temperature	Resettable error	Reduce motor load rate

AL.02.D	Release resistor overload	Resettable error	After releasing the resistor overload, it can't continue to release. It is necessary to increase the power of the braking resistor and set correct parameters to P02.20~ P02.24, or increase the heat dissipation coefficient of the releasing resistor of P02.38
AL.03.0	MCU lost	Non-resettable error	Please contact our personnel
AL.03.1	FPGA interrupt timeout	Non-resettable error	Please contact our personnel
AL.03.2	Current sampling timeout	Non-resettable error	Please contact our personnel
AL.03.3	Encoder timeout	Non-resettable error	Check the cable of encoder
AL.03.4	FPGA operation timeout	Non-resettable error	Please contact our personnel
AL.04.0	No corresponding drive	Non-resettable error	P19.00 setting error, no corresponding driver model, Please contact our personnel for change
AL.04.1	No corresponding motor	Non-resettable error	P18.00 setting error, no corresponding driver model, Please contact our personnel for change
AL.04.4	DI error	Resettable error	In case of DI function allocation failure, allocated the same DI function should to different DI; in case of frequency division errors, modify the function code settings and make changes
AL.04.5	Electronic gear ratio setting error	Resettable error	Modify the ratio of electronic gear (P03.12~P03.18) to make it within the correct Setting range.
AL.04.6	Frequency division output setting failure	Resettable error	The number of frequency division output pulses is greater than the frequency division rate of encoder, so it is necessary to reset P02.03
AL.04.8	Soft limit setting failure	Resettable error	Upper limit of software position limit (P03.23) is less than lower limit (P03.21)
AL.04.9	Home position setting error	Resettable error	The mechanical home offset P03.36 is set outside the soft limit, the upper limit of the software position limit is (P03.23), the lower limit is (p03.21),

			P03.36 needs to be reset
AL.04.A	The resistance of external release resistor is too small	Warning	Change a suitable release resistor and set it to the correct value (P02.22)
AL.05.0	Positive overshoot	Warning	External (or software limit) positive over-travel signal is detected, and the servo no longer responds to the positive command
AL.05.1	Negative overshoot	Warning	External (or software limit) negative over-travel signal is detected, and the servo no longer responds to the negative command
AL.05.2	Emergency stop	Warning	External shutdown signal detected
AL.05.3	Excessive position deviation	Resettable error	Position deviation is greater than P03.26 set value detect if there is mechanical jamming Increase P03.26 set value Increase the gain, and add position smoothing filtering processing
AL.05.4	Home position reset timeout error	Warning	Time-out error in homing, with homing time exceeding the set value of P03.35
AL.05.5	Runaway velocity alarm	Resettable error	UVW wiring error Electric angle error Encoder cable abnormal; check whether the feedback display is correct Check whether P18.00 is set correctly
AL.05.6	Overvelocity	Resettable error	UVW wiring error Electric angle error Gain setting unreasonable Encoder cable abnormal; check feedback display
AL.05.7	Servo enable failure	Resettable error	When Fn auxiliary function is used, external servo enable DI is effective
AL.05.8	STO protection	Warning	STO signal input
AL.05.9	Excessive internal and external deviation of full closed loop	Resettable error	Check whether external encoder feedback is correct Check whether the feedback direction of the external encoder is correct Check whether the machine slips or not Set correct and suitable deviation range

AL.06.0	Abnormal pulse input	Resettable error	Pulse input frequency is more than 4M reduce the upper computer's pulse frequency Check whether the pulse input wiring, shielding wire and grounding are correct
AL.06.1	Abnormal pulse input	Resettable error	Pulse input frequency is more than 4M reduce the upper computer's pulse frequency Check whether the pulse input wiring, shielding wire and grounding are correct
AL.06.2	Abnormal frequency division output	Resettable error	Frequency division output velocity is greater than 4m It is acceptable to reduce the output pulse number by one turn (P02.03)
AL.06.3	EERPOM read exception	Resettable error	Communication read function code too frequently It is acceptable to set P09.10 to 1
AL.06.4	EERPOM write exception	Resettable error	Communication read function code too frequently It is acceptable to set P09.10 to 1
AL.06.5	EERPOM exception	Resettable error	EEPROM is operated too frequently
AL.06.6	Ai1 voltage input too high	Resettable error	Ai1 input too large
AL.07.0	Angle identification failure	Resettable error	Make sure UVW wiring is correct Check whether the motor parameters are set correctly, and whether the polar number, resolution and polar distance required for linear motor are set correctly. Contact our personnel
AL.07.1	Angle identification failure 1	Resettable error	Make sure UVW wiring is correct The encoder cable is abnormal; Check whether the position feedback is correct Check whether the motor parameters are set correctly, and whether the polar number, resolution and polar distance required for linear motor are set correctly. Contact our personnel
AL.07.2	Angle identification failure 2	Resettable error	Make sure UVW wiring is correct The encoder cable is abnormal; Check whether the position feedback is correct

			Contact our personnel
AL.07.3	Offline inertia identification failure	Resettable error	Check for correct UVW wiring Check for mechanical jamming Check for normal motor rotation.
AL.07.4	Angle identification stalling	Resettable error	Check for motor blocked during angle identification. Check for UVW correct mechanically Check for mechanical jamming
AL.0A.0	Power on again is required for parameters to get effective	Warning	The set parameters need to be powered on again.
AL.0A.2	Power phase loss warning	Warning	Check for loss of phase of the input of external power supply, or it is acceptable to use P07.05 = 2 to shield such warning
AL.0A.4	Motor overload warning	Warning	Motor overload warning; reduce average load
AL.0A.5	Motor power line disconnected	Warning	Check whether UVW is wired
AL.0A.6	Encoder external battery undervoltage	Warning	Check the circuit of external battery of encoder and check whether the battery voltage is normal
AL.0A.7	Encoder overheated	Warning	Reduce the load rate and check whether the motor is heated seriously
AL.10.0	Encoder disconnected	Non-resettable error	Check whether P18.00 is set correctly Check whether the encoder wiring is correct
AL.10.1	Encoder parameter error	Non-resettable error	Data verification error or parameter not stored in EEPROM of motor
AL.10.2	Encoder communication failure	Non-resettable error	Check whether P18.00 is set correctly Check whether the encoder wiring is correct
AL.10.3	Error in encoder resolution	Non-resettable error	Check whether P18.00 is set correctly Check whether the encoder wiring is correct
AL.10.4	Encoder count increment exception	Non-resettable error	Check whether P18.00 is set correctly Check whether the encoder wiring is correct
AL.10.5	Encoder parameter write failure	Non-resettable error	Check whether P18.00 is set correctly Check whether the encoder wiring is

			correct
AL.10.6	Encoder battery failure	Non-resettable error	Check whether the external battery is disconnected or the battery level is low It is acceptable to reset the error using Fn07
AL.10.7	Encoder multi-ring count error	Non-resettable error	Check whether the external battery is disconnected or the battery level is low It is acceptable to reset the error using Fn07
AL.10.8	Encoder multi-ring counter overflow	Non-resettable error	It is acceptable to reset the error using Fn07
AL.10.9	Encoder parameter read-write check exception	Non-resettable error	Check whether P18.00 is set correctly Check whether the encoder wiring is correct
AL.10.A	AB interference of incremental encoder	Non-resettable error	Check the wiring of encoder
AL.10.B	Z interference fault of incremental encoder	Non-resettable error	Check the wiring of encoder
AL.10.C	Error after power on incremental encoder	Non-resettable error	Check whether the wiring of encoder is correct, or whether the setting of encoder type p18.00 is wrong, or whether the motor encoder is faulty
AL.10.D	Incremental encoder disconnected	Non-resettable error	Check the wiring of encoder

Chapter 10 List of Function Code

10.1 List of parameter

Related modeP stands for the position mode, S stands for the velocity mode, T stands for the torque mode, and “*” in the Unit Table stands for the Unit in case of linear motor used.

P00group gain parameter

Function code		Description	Setting range	Unit	Default Setting	Manner of getting effective
P00	00	Self adjusting mode selection	0-manual gain adjustment 1-automatic rigid table adjustment 2-positioning mode 1 3-positioning mode 2	-	1	Effective immediately
P00	01	Group 1 response level selection	1~31	-	11	Effective immediately
P00	02	Group 1 velocity loop gain	1~20000	0.1HZ	250	Effective immediately
P00	03	Group 1 velocity loop integration time constant	15~51200	0.01ms	3183	Effective immediately
P00	04	Group 1 position loop gain	0~20000	0.1HZ	400	Effective immediately
P00	05	Group 1 torque filtering constant	0~3000	0.01ms	79	Effective immediately
P00	06	Group 2 velocity loop gain	1~20000	0.1HZ	250	Effective immediately
P00	07	Group 2 velocity loop integration time constants	15~51200	0.01ms	3183	Effective immediately
P00	08	Group 2 position loop gain	0~20000	0.1HZ	400	Effective immediately
P00	09	Group 2 torque filtering constant	0~3000	0.01ms	79	Effective immediately
P00	0A	Load inertia ratio	0~1200	0.01	100	Effective immediately
P00	0C	Torque command filter selection	0- First order low-pass filter 1- Double second	-	0	Effective immediately

Function code		Description	Setting range	Unit	Default Setting	Manner of getting effective
			order filter			
P00	0D	Single parameter adjustment Zeta value	100~6000	0.01	150	Effective immediately
P00	0E	Single parameter adjustment Nvp value	100~6000	0.01	150	Effective immediately
P00	10	Velocity feedpositive gain	0~1000	0.1%	0	Effective immediately
P00	11	Velocity feedpositive filtering time	0~6400	0.01ms	50	Effective immediately
P00	12	PDFF control factor	0~1000	0.1%	1000	Effective immediately
P00	14	Torque feedpositive gain	0~1000	0.1%	0	Effective immediately
P00	15	Torque feedpositive filtering time	0~6400	0.01ms	50	Effective immediately
P00	20	Velocity feedback average filtering	0~4	-	0	Effective immediately
P00	21	Velocity feedback low-pass filtering	50~5000	HZ	5000	Effective immediately
P00	22	Torque observer cutoff frequency	1~5000	HZ	400	Effective immediately
P00	23	Torque observer proportional gain	1~8000	HZ	400	Effective immediately
P00	24	Velocity observer position compensation gain	0~3000	HZ	0	Effective immediately
P00	25	Model loop enable	0-disable 1- enable			Effective immediately
P00	26	Model loop gain	0~20000	0.1HZ	400	Effective immediately

P01 group vibration suppression parameters						
Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P01	00	Adaptive filter mode selection	0-adaptive notch filter does not update manual setting 1- one adaptive notch filter (group 3 is effective) 2-two adaptive notch filters (group 3 and group 4 are effective) 3-only test results are shown in P01.01 4-restore the set notch filter to default setting	-	0	Effective after shutdown
P01	01	Vibration determination threshold	1~1000	0.1%	20	Effective immediately
P01	02	Resonance frequency identification results	0~5000	HZ	250	Effective immediately
P01	04	Group 1 notch filter anti resonance frequency	10~5000	HZ	5000	Effective immediately
P01	05	Group 1 notch filter frequency	50~5000	HZ	5000	Effective immediately
P01	06	Group 1 notch filter band width	0~20	-	2	Effective immediately
P01	07	Group 1 notch filter attenuation level	0~99	-	0	Effective immediately
P01	08	Group 2 notch filter antiresonance frequency	10~5000	HZ	5000	Effective immediately
P01	09	Group 2 notch filter frequency	50~5000	HZ	5000	Effective immediately

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P01	0A	Group 2 notch filter band width	0~20	-	2	Effective immediately
P01	0B	Group 2 notch filter attenuation level	0~99	-	0	Effective immediately
P01	0C	Group 3 notch filter anti-resonance frequency	10~5000	HZ	5000	Effective immediately
P01	0D	Group 3 notch filter frequency	50~5000	HZ	5000	Effective immediately
P01	0E	Group 3 notch filter band width	0~20	-	2	Effective immediately
P01	0F	Group 3 notch filter attenuation level	0~99	-	0	Effective immediately
P01	10	Group 4 notch filter anti-resonance frequency	10~5000	HZ	5000	Effective immediately
P01	11	Group 4 notch filter frequency	50~5000	HZ	5000	Effective immediately
P01	12	Group 4 notch filter band width	0~20	-	2	Effective immediately
P01	13	Group 4 notch filter attenuation level	0~99	-	0	Effective immediately
P01	1A	Disturbance torque compensation gain	0~1000	0.1%	0	Effective immediately
P01	1B	Disturbance observer filter time	0~2500	0.01ms	50	Effective immediately
P01	1C	Constant torque compensation value	-1000~1000	0.1%	0	Effective immediately
P01	1D	Positive friction compensation value	-1000~1000	0.1%	0	Effective immediately
P01	1E	Negative friction compensation value	-1000~1000	0.1%	0	Effective immediately
P01	1F	Servo low-frequency vibration position deviation judgment threshold	0~65535	p	10	Effective immediately
P01	21	Low frequency resonance frequency A	0~1000	0.1HZ	1000	Effective immediately

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P01	22	Low frequency resonance frequency A filter setting	0~10	-	2	Effective immediately
P01	23	Low frequency resonance frequency amplification factor	12~30	0.1	12	Effective immediately

P02 Group Basic Parameter Setting

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P02	00	Mode selection	0-velocity mode 1-position mode 2-torque mode 3-DI switch mixed mode	-	0	Effective after shutdown
P02	01	Running direction selection	0-cw positive direction 1-ccw negative direction	-	0	Effective after re-power-on
P02	02	Frequency division output pulse phase	0-A ahead of B 1-B ahead of A	-	0	Effective after re-power-on
P02	03	Frequency division output pulse number	1~1048576	-	2500	Effective after re-power-on
P02	05	Z-pulse output polarity setting ,	0- positive polarity 1- negative polarity	-	0	Effective after re-power-on
P02	07	Velocity feedback source selection	0-encoder direct feedback 1-velocity observer	-	0	Effective after shutdown
P02	09	Enable automatic model identification	0- Enable automatic identification 1- Disable automatic identification	-	0	Effective after re-power-on
P02	0A	Set the default display status of the panel				
P02	0B	Enable absolute value encoder alarm	0- disable absolute value alarm 1- enable absolute alarm	-	0	Effective after shutdown
P02	10	Servo OFF shutdown mode	-2 : Slope shutdown, with DB braking	-	0	Effective after shutdown

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
		selection	-1 : DB shutdown DB status 0 : Free shutdown, keeping operating freely. 1 : Slope shutdown, keeping operating freely. 2 : Zero-velocity shutdown, keeping operating freely.			
P02	11	Overtravel stop mode	0-shutting down freely 1- Zero-velocity shutdown	-	2	Effective after shutdown
P02	12	Fault 1 shutdown mode selection	0-shutting down freely 1-DB shutdown free state 2-DB shutdown, keeping DB state	-	0	Effective after shutdown
P02	13	Fault 2 shutdown mode selection	-4-Emergency torque shutdown, keeping DB State -3-Slope shutdown, keeping DB State -2-Slope shutdown, keeping DB State -1-DB shutdown, keeping DB state 0-Free shutdown, keeping operating freely. 1-Slope shutdown, keeping operating freely. 2-Slope shutdown, keeping operating freely. 3-Emergency torque shutdown, keeping operating freely			Effective after shutdown

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P02	14	Shutdown mode and shutdown state switching velocity threshold	10~1000	rpm (*mm/s)	100	Effective after shutdown
P02	18	Brake enable	0-brake disabled 1-brake enable	-	0	Effective after shutdown
P02	19	Delay from brake output ON to command receiving	0~500	ms	200	Effective after shutdown
P02	1A	Delay from brake output Off to motor de-energized	50~1000	ms	150	Effective after shutdown
P02	1B	Velocity threshold when brake output Off	20~300	rpm (*mm/s)	30	Effective after shutdown
P02	1C	Delay from servo Off to brake output Off	1~1000	ms	500	Effective after shutdown
P02	20	Setting of energy consumption resistor	0-built in resistor 1-external resistor 2-air cooling of external resistor 3- no release.	-		Effective after shutdown
P02	21	Power capacity of external energy consumption resistor	1~65535	W	800	Effective after shutdown
P02	22	Resistance value of external energy consumption resistor	1~1000	Ω	50	Effective after shutdown
P02	23	Minimum value of energy consumption resistor allowable for driver	1~1000	Ω	40	Effective after shutdown
P02	24	Power capacity of built-in energy consumption resistor	1~65535	W	50	Effective after shutdown
P02	25	Resistance of built-in energy consumption resistor	0~1000	Ω	40	Effective after shutdown

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P02	26	Heat dissipation coefficient of resistor	0~1000	%	60	Effective after shutdown
P02	29	Password set by manufacturer	0~65535	-	-	Effective immediately

P03group position mode parameters

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P03	00	Source of position command	0- pulse 1 - internal position mode	-	0	Effective after shutdown
P03	02	Shape of command pulse	0-direction + pulse positive logic 1-direction + pulse negative logic 2-AB orthogonal 3-CW / CCW	-	0	Effective after re-power-on
P03	03	Effective selection of pulse edge	0-effective rising edge 1-effective falling edge	-	0	Effective after re-power-on
P03	04	Input pulse filtering time	0~255	25ns	10	Effective after re-power-on
P03	06	Instruction FIR filtering time constant	0~65535	0.01ms	0	Effective after shutdown
P03	07	Moving average time of position command	0~1280	0.01ms	0	Effective after shutdown
P03	10	Number of command pulses per revolution of motor	0~8388608	-	0	Effective after shutdown
P03	12	Group 1 electronic gear molecules	1~ 1073741824	-	10	Effective after shutdown
P03	14	Group 1 electronic gear denominator	1~ 1073741824	-	1	Effective after shutdown
P03	16	Group 2 electronic gear molecules	1~ 1073741824	-	10	Effective after shutdown
P03	18	Group 2 electronic gear denominator	1~ 1073741824	-	1	Effective after shutdown

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P03	20	Soft limit function selection	0-disable soft limit function 1-enable soft limit function 2-enable soft limit function after homing			Effective after shutdown
P03	21	Soft limit minimum value	-2147483648~2147483648	p	0	Effective after shutdown
P03	23	Soft limit maximum value	-2147483648~2147483648	p	0	Effective after shutdown
P03	26	Fault set value of excessive position deviation	1~ 1073741824	p	3145728	Effective after shutdown
P03	31	Reset mode of home	0~36	-	3	Effective immediately
P03	32	High-velocity search velocity of home	1~1000	rpm (*mm/s)	100	Effective immediately
P03	33	Low-velocity search velocity of home	1~1000	rpm (*mm/s)	10	Effective immediately
P03	34	Acceleration and deceleration time of home	0~10000	ms	10	Effective immediately
P03	35	Search time of home	0~60000	ms	50000	Effective immediately
P03	36	Mechanical offset of home	-2147483648~2147483648	P	0	Effective immediately
P03	38	Fixed length displacement of probe	-2147483648~2147483648	P	10000	Effective immediately
P03	3A	Fixed length velocity of probe	0~6000	rpm	1000	Effective immediately
P03	3B	Fixed length acceleration and deceleration time of probe	0~65535	ms	100	Effective immediately
P03	3C	Configuration of probe	0~0xFFFF		0	Effective immediately
P03	3D	Filtering time Unit of probe	0~255	25ns	5	effective after re-power-on

P04group velocity torque parameters

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P04	00	Velocity command	0-Digital setting 1-AI	-	0	Effective after shutdown
P04	01	Velocity command digital setting	-9000~9000	rpm (*mm/s)	300	Effective immediately
P04	02	Di jogging velocity setting value	-9000~9000	rpm (*mm/s)	20	Effective immediately
P04	03	Velocity command acceleration time	0~65535	ms	20	Effective immediately
P04	04	Velocity command deceleration time	0~65535	ms	20	Effective immediately
P04	06	Jog velocity acceleration ramp time	0~65535	ms	20	Effective immediately
P04	07	Analog 10V corresponding velocity	0~10000	rpm (*mm/s)	3000	Effective immediately
P04	0A	Torque command selection	0- Digital Setting 1- 1-AI	-	0	Effective after shutdown
P04	0B	Torque command keyboard setting	-3000~3000	0.1%	0	Effective immediately
P04	0B	Analog 10V corresponding torque value	0~8000	0.1%	1000	Effective immediately
P04	0D	Torque command acceleration time	0~65535	ms	0	Effective immediately
P04	0E	Torque command deceleration time	0~65535	ms	0	Effective immediately
P04	0F	Emergency stop torque	0~3000	0.1%	1000	Effective after shutdown
P04	10	Positive limit of velocity	0~6000	rpm (*mm/s)	6000	Effective immediately
P04	11	Negative limit of velocity	0~6000	rpm (*mm/s)	6000	Effective immediately
P04	12	Positive limit of torque	0~3500	0.1%	3000	Effective immediately
P04	13	Negative limit of torque	0~3500	0.1%	3000	Effective immediately
P04	14	Positive limit value of internal velocity during torque control	0~6000	rpm (*mm/s)	3000	Effective immediately

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P04	15	Negative limit value of internal velocity during torque control	0~6000	rpm (*mm/s)	3000	Effective immediately

P05 group input parameters

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P05	00	DI function source selection bit0~bit15	0~65535	-	0	Effective after shutdown
P05	01	DI function source selection bit16~bit31	0~65535	-	0	Effective after shutdown
P05	02	DI function source selection bit32~bit47	0~65535	-	0	Effective after shutdown
P05	03	DI function source selection bit48~bit63	0~65535	-	0	Effective after shutdown
P05	04	DI1 terminal function selection	0~30	-	1	Effective after shutdown
P05	05	DI1 terminal logic selection	0-active low 1-active high	-	0	Effective after shutdown
P05	06	DI2 terminal function selection	0~30	-	0	Effective after shutdown
P05	07	DI2 terminal logic selection	0-active low 1-active high	-	0	Effective after shutdown
P05	08	DI3 terminal function selection	0~30	-	0	Effective after shutdown
P05	09	DI3 terminal logic selection	0-active low 1-active high	-	0	Effective after shutdown
P05	0A	DI4 terminal function selection	0~30	-	0	Effective after shutdown
P05	0B	DI4 terminal logic selection	0-active low 1-active high	-	0	Effective after shutdown
P05	0C	DI5 terminal function selection	0~30	-	0	Effective after shutdown
P05	0D	DI5 terminal logic selection	0-active low 1-active high	-	0	Effective after shutdown
P05	0E	DI6 terminal function selection	0~30	-	0	Effective after shutdown

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P05	0F	DI6 terminal logic selection	0-active low 1-active high	-	0	Effective after shutdown
P05	10	DI7 terminal function selection	0~30	-	0	Effective after shutdown
P05	11	DI7 terminal logic selection	0-active low 1-active high	-	0	Effective after shutdown
P05	12	DI8 terminal function selection	0~30	-	0	Effective after shutdown
P05	13	DI8 terminal logic selection	0-active low 1-active high	-	0	Effective after shutdown
P05	2A	Virtual DI logic setting bit0~bit15	0~65535	-	0	Effective after shutdown
P05	2B	Virtual DI logic setting bit16~bit31	0~65535	-	0	Effective after shutdown
P05	2C	Virtual DI logic setting bit32~bit47	0~65535	-	0	Effective after shutdown
P05	2D	Virtual DI logic setting bit48~bit63	0~65535	-	0	Effective after shutdown
P05	30	AI1 offset	-5000~5000	1mv	0	Effective immediately
P05	31	Input filtering time	0~65535	0.01ms	200	Effective immediately
P05	32	AI1dead zone	0~10000	0.1mv	100	Effective immediately
P05	33	AI1 null shift	-5000~5000	0.1mv	0	Effective immediately
P05	40	DI filtering time	0~65535	0.01us	1000	Effective immediately

P06 group output parameters

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P06	00	DO1 terminal function selection	0~20	-	5	Effective after shutdown
P06	01	DO1 terminal logic selection	0- active low 1- 1-active high	-	0	Effective after shutdown
P06	02	DO2 terminal function selection	0~20	-	6	Effective after shutdown
P06	03	DO2 terminal logic selection	2- active low 3- active high	-	0	Effective after shutdown
P06	04	DO3 terminal function selection	0~20	-	0	Effective after shutdown

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P06	05	DO3 terminal logic selection	0-active low 1-active high	-	0	Effective after shutdown
P06	06	DO4 terminal function selection	0~20	-	0	Effective after shutdown
P06	07	DO4 terminal logic selection	0-active low 1-active high	-	0	Effective after shutdown
P06	08	DO5 terminal function selection	0~20	-	0	Effective after shutdown
P06	09	DO5 terminal logic selection	0-active low 1-active high	-	0	Effective after shutdown
P06	20	Virtual DO logic setting bit0~bit15	0~65535	-	0	Effective after shutdown
P06	21	Virtual DO logic setting bit16~bit31	0~65535	-	0	Effective after shutdown
P06	22	Virtual DO logic setting bit32~bit47	0~65535	-	0	Effective after shutdown
P06	23	Virtual DO logic setting bit48~bit63	0~65535	-	0	Effective after shutdown
P06	2C	Positioning completion range	100	p	0	Effective immediately
P06	2D	Positioning completion hold time	0~2000	ms	0	Effective immediately
P06	2E	Position reach window unit setting	0 -user's Unit 1-encoder's Unit	-	0	Effective immediately
P06	30	Zero velocity clamp / zero fixed velocity command threshold	0~6000	rpm (*mm/s)	10	Effective immediately
P06	31	Motor rotation state threshold	1~1000	rpm (*mm/s)	20	Effective immediately
P06	32	Velocity consistent signal width	1~200	rpm (*mm/s)	10	Effective immediately
P06	33	Velocity reach signal threshold	10~6000	rpm (*mm/s)	1000	Effective immediately
P06	34	Zero velocity output signal threshold	1~200		10	Effective immediately
P06	35	Velocity DO filter time	0~65535	0.1ms	0	Effective immediately
P06	3A	Torque reaches reference value	0~3000	0.1%	0	Effective immediately
P06	3B	Output torque value when torque reach DO signal is on	200~3000	0.1%	200	Effective immediately

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P06	3C	Output torque value when torque reach DO signal is off	100~3000	0.1%	100	Effective immediately

P07group extended function parameters

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P07	00	Stalling over-temperature protection enable	0~disable 1-enable	-	1	Effective immediately
P07	01	Turn-off motor overload warning	0-not shut down 1- shut down	-	0	Effective immediately
P07	02	Runaway protection selection	0-shield runaway alarm 1-enable runaway alarm	-	1	Effective after shutdown
P07	03	Encoder multi-ring overflow fault prohibition	0- enable alarm 1-shield alarm	-	1	Effective after shutdown
P07	04	UVW Phase sequence identification enable	0- disable phase sequence identification 1- enable phase sequence identification	-	1	Effective after shutdown
P07	05	Power input phase loss protection selection	0-enable absent alarm 1-enable absent alarm 2-shield missing item	-	0	Effective immediately
P07	06	Fault record save switch	0-save 1-unsave	-	0	Effective after shutdown
P07	07	Power failure save EEPROM enable	0 - no power failure save 1-enable power failure save	-	0	Effective after shutdown
P07	08	Shield model identification	0-use automatic model identification 1-set the model manually	-	0	Effective after shutdown
P07	09	Set the default display status of the panel	0~0x25 After use, the panel displays the status corresponding to U00.XX by default			Effective after shutdown

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P07	10	Stalling over-temperature protection time window	10~1000	ms	20	Effective immediately
P07	11	Motor overload protection gain	50~300	%	100	Effective immediately
P07	12	Linear motor PTC alarm enable	0~ no alarm. 1~ alarm	-	0	Effective immediately
P07	14	Over velocity judgment threshold	0~65535	rpm (*mm/s)	0	Effective after shutdown
P07	15	Velocity display filtering time	0~5000	ms	0	Effective after shutdown
P07	1A	Nikon encoder reset when powered on	0 - no reset after power on 1-reset after power on	-	-	Effective after shutdown
P07	1B	ROM disabled when encoder is powered on	0 - do not read motor parameters 1 - read motor parameters	-	-	Effective after shutdown
P07	1D	Enable offline detection	0-disable 1-enable	-	0	Effective after shutdown
P07	20	Slope shutdown acceleration and deceleration time	0~10000	ms	50	Effective immediately
P07	21	Emergency stop acceleration and deceleration time	0~10000	ms	5	Effective immediately
P07	22	Torque stop torque acceleration	0~3000	0.1%	500	Effective immediately

P08 full closed-loop parameters

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P08	00	Full closed-loop operation mode	0 ~ disable full closed-loop 1-enable full closed-loop	-	0	Effective immediately
P08	01	External encoder running direction selection	0- positive 1- negative	-	0	effective after re-power-on
P08	02	External encoder resolution	0~8388608	-	10000	Effective after shutdown

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P08	04	Full closed-loop vibration suppression gain	-300.0~300.0	-	1	Effective after shutdown
P08	05	Full closed-loop vibration suppression cutoff frequency	10~5000	HZ	500	Effective after shutdown
P08	06	Full closed loop velocity feedback correction coefficient	0~120.0	-	100.0	
P08	07	Filtering time constant of inner and outer loop position deviation	0~1000	ms	0	Effective after shutdown
P08	0C	Maximum allowable deviation of internal and external loop encoder	0~2,147,483,648	External encoder's Unit	0	Effective after shutdown
P08	0E	Actual deviation of internal and external loop encoder	Display	External encoder's Unit		
P08	10	Internal encoder count value	Display	Encoder's Unit		
P08	12	External encoder count value	Display	External encoder's Unit		

P09 group modbus communication parameters

Function code		Description	Setting range	Unit	default setting	Manner of getting effective
P09	00	485 communication node	0~128	-	1	Effective immediately
P09	01	Baud rate setting	0.-2400 1-4800 2-9600 3-19200 4-38400 5-57600 6-115200	-	6	Effective immediately
P09	02	Data format	0-no check 2 stop		0	Effective

Function code		Description	Setting range	Unit	default setting	Manner of getting effective
			bits 1-even check 1 stop bit 2-odd check 1 stop bit 3-no check 1 stop bit			immediately
P09	03	Delay response time	100	ms	0	Effective immediately
P09	0A	232 baud rate setting	0.-2400 1-4800 2-9600 3-19200 4-38400 5-57600 6-115200	-	6	Effective immediately
P09	10	485 communication function code forbid to save EEPROM or not	0- save EEPROM 1- Unsave EEPROM	-	0	Effective immediately

P0A group extended parameter group

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P0A	00	Offline inertia identification mode	0. Positive and negative operation mode 1. Single direction operation mode	-	1	Effective immediately
P0A	02	Maximum velocity reached during inertia identification	100~1000	rpm (*mm/s)	500	Effective after shutdown
P0A	03	Time of acceleration to maximum velocity in inertia identification	20~800	ms	120	Effective after shutdown
P0A	0A	UVW phase sequence identification enable	0-disable phase sequence identification 1-enable phase sequence			

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
			identification			
P0A	0B	Selection of angle identification mode	0- pre-positioning 1-open-loop jogging 2-closed-loop jogging	-	0	Effective after shutdown
P0A	0C	Electric angle action window of angle identification micromotion method	0~900		2	Effective after shutdown
P0A	0D	Stop window of angle identification jogging method	0~100	p	3	Effective after shutdown
P0A	0E	Setting electric angle by direct pre-positioning method	0~1800	0.1 °	10	Effective after shutdown
P0A	0F	Determine whether Hall signal identification is necessary	0-disable hall identification 1-enable hall identification	-	0	Effective after shutdown

P10 group internal position group

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P10	00	Internal position operation mode selection	0- Single operation 1- Cyclic operation	-	0	Effective immediately
P10	03	Number of operation segments in internal position	1~16	-	3	Effective immediately
P10	08	Displacement of Segment 1	-2147483648~2147483648	User's Unit	10000	Effective immediately
P10	0A	Velocity of Segment 1	0~9000	Rpm (mm/s)	300	Effective immediately
P10	0B	Acceleration time of Segment 1	0~65535	ms	10	Effective immediately
P10	0C	Deceleration time of Segment 1	0~65535	ms	10	Effective immediately
P10	0D	Waiting time of Segment 1	0~65535	ms	0	Effective immediately
P10	0E	Property	0 ~ absolute	-	0	Effective

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
		configuration of Segment 1	displacement 1 ~ incremental displacement			immediately
P10	0F	Displacement of Segment 2	-2147483648~2147483648	User's Unit	10000	Effective immediately
P10	11	Velocity of Segment 2	0~9000	Rpm (mm/s)	300	Effective immediately
P10	12	Acceleration time of Segment 2	0~65535	ms	10	Effective immediately
P10	13	Deceleration time of Segment 2	0~65535	ms	10	Effective immediately
P10	14	Waiting time of Segment 2	0~65535	ms	0	Effective immediately
P10	15	Property configuration of Segment 2	0~Absolute displacement 1~Incremental displacement	-	0	Effective immediately
P10	16	Displacement of Segment 3	-2147483648~2147483648	user's Unit	10000	Effective immediately
P10	18	Velocity of Segment 3	0~9000	Rpm (mm/s)	300	Effective immediately
P10	19	Acceleration time of Segment 3	0~65535	ms	10	Effective immediately
P10	1A	Deceleration time of Segment 3	0~65535	ms	10	Effective immediately
P10	1B	Waiting time of Segment 2	0~65535	ms	0	Effective immediately
P10	1C	Property configuration of Segment 3	0~Absolute displacement 1~Incremental displacement	-	0	Effective immediately
P10	1D	Displacement of Segment 4	-2147483648~2147483648	User's Unit	10000	Effective immediately
P10	1F	Velocity of Segment 4	0~9000	Rpm (mm/s)	300	Effective immediately
P10	20	Acceleration time of Segment 4	0~65535	ms	10	Effective immediately
P10	21	Deceleration time of Segment 4	0~65535	ms	10	Effective immediately
P10	22	Waiting time of Segment 4	0~65535	ms	0	Effective immediately
P10	23	Property configuration of Segment 4	0~Absolute displacement 1~Incremental	-	0	Effective immediately

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
			displacement			
P10	24	Displacement of Segment 5	-2147483648~2147483648	User's Unit	10000	Effective immediately
P10	26	Velocity of Segment 5	0~9000	Rpm (mm/s)	300	Effective immediately
P10	27	Acceleration time of Segment 5	0~65535	ms	10	Effective immediately
P10	28	Deceleration time of Segment 5	0~65535	ms	10	Effective immediately
P10	29	Waiting time of Segment 5	0~65535	ms	0	Effective immediately
P10	2A	Property configuration of Segment 5	0~Absolute displacement 1~Incremental displacement	-	0	Effective immediately
P10	2B	Displacement of Segment 6	-2147483648~2147483648	User's Unit	10000	Effective immediately
P10	2D	Velocity of Segment 6	0~9000	Rpm (mm/s)	300	Effective immediately
P10	2E	Acceleration time of Segment 6	0~65535	ms	10	Effective immediately
P10	2F	Deceleration time of Segment 6	0~65535	ms	10	Effective immediately
P10	30	Waiting time of Segment 6	0~65535	ms	0	Effective immediately
P10	31	Property configuration of Segment 6	0~Absolute displacement 1~Incremental displacement	-	0	Effective immediately
P10	32	Displacement of Segment 7	-2147483648~2147483648	User's Unit	10000	Effective immediately
P10	34	Velocity of Segment 7	0~9000	Rpm (mm/s)	300	Effective immediately
P10	35	Acceleration time of Segment 7	0~65535	ms	10	Effective immediately
P10	36	Deceleration time of Segment 7	0~65535	ms	10	Effective immediately
P10	37	Waiting time of Segment 2	0~65535	ms	0	Effective immediately
P10	38	Property configuration of Segment 7	0~Absolute displacement 1~Incremental displacement	-	0	Effective immediately

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P10	39	Displacement of Segment 8	-2147483648~2147483648	User's Unit	10000	Effective immediately
P10	3B	Velocity of Segment 8	0~9000	Rpm (mm/s)	300	Effective immediately
P10	3C	Acceleration time of Segment 8	0~65535	ms	10	Effective immediately
P10	3D	Deceleration time of Segment 8	0~65535	ms	10	Effective immediately
P10	3E	Waiting time of Segment 8	0~65535	ms	0	Effective immediately
P10	3F	Property configuration of Segment 8	0~Absolute displacement 1~Incremental displacement	-	0	Effective immediately
P10	40	Displacement of Segment 9	-2147483648~2147483648	User's Unit	10000	Effective immediately
P10	42	Velocity of Segment 9	0~9000	Rpm (mm/s)	300	Effective immediately
P10	43	Acceleration time of Segment 9	0~65535	ms	10	Effective immediately
P10	44	Deceleration time of Segment 9	0~65535	ms	10	Effective immediately
P10	45	Waiting time of Segment 9	0~65535	ms	0	Effective immediately
P10	46	Property configuration of Segment 9	0~Absolute displacement 1~Incremental displacement	-	0	Effective immediately
P10	47	Displacement of Segment 10	-2147483648~2147483648	User's Unit	10000	Effective immediately
P10	49	Velocity of Segment 10	0~9000	Rpm (mm/s)	300	Effective immediately
P10	4A	Acceleration time of Segment 10	0~65535	ms	10	Effective immediately
P10	4B	Deceleration time of Segment 10	0~65535	ms	10	Effective immediately
P10	4C	Waiting time of Segment 10	0~65535	ms	0	Effective immediately
P10	4D	Property configuration of Segment 10	0~Absolute displacement 1~Incremental displacement	-	0	Effective immediately
P10	4E	Displacement of Segment 11	-2147483648~2147483648	User's Unit	10000	Effective immediately

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P10	50	Velocity of Segment 11	0~9000	Rpm (mm/s)	300	Effective immediately
P10	51	Acceleration time of Segment 2	0~65535	ms	10	Effective immediately
P10	52	Deceleration time of Segment 11	0~65535	ms	10	Effective immediately
P10	53	Waiting time of Segment 11	0~65535	ms	0	Effective immediately
P10	54	Property configuration of Segment 11	0~Absolute displacement 1~Incremental displacement	-	0	Effective immediately
P10	55	Displacement of Segment 12	-2147483648~2147483648	User's Unit	10000	Effective immediately
P10	57	Velocity of Segment 12	0~9000	Rpm (mm/s)	300	Effective immediately
P10	58	Acceleration time of Segment 12	0~65535	ms	10	Effective immediately
P10	59	Deceleration time of Segment 12	0~65535	ms	10	Effective immediately
P10	5A	Waiting time of Segment 12	0~65535	ms	0	Effective immediately
P10	5B	Property configuration of Segment 12	0~Absolute displacement 1~Incremental displacement	-	0	Effective immediately
P10	5C	Displacement of Segment 13	-2147483648~2147483648	User's Unit	10000	Effective immediately
P10	5E	Velocity of Segment 13	0~9000	Rpm (mm/s)	300	Effective immediately
P10	5F	Acceleration time of Segment 13	0~65535	ms	10	Effective immediately
P10	60	Deceleration time of Segment 13	0~65535	ms	10	Effective immediately
P10	61	Waiting time of Segment 13	0~65535	ms	0	Effective immediately
P10	62	Property configuration of Segment 13	0~Absolute displacement 1~Incremental displacement	-	0	Effective immediately
P10	63	Displacement of Segment 14	-2147483648~2147483648	User's Unit	10000	Effective immediately
P10	65	Velocity of Segment 14	0~9000	Rpm (mm/s)	300	Effective immediately

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P10	66	Acceleration time of Segment 14	0~65535	ms	10	Effective immediately
P10	67	Deceleration time of Segment 14	0~65535	ms	10	Effective immediately
P10	68	Waiting time of Segment 14	0~65535	ms	0	Effective immediately
P10	69	Property configuration of Segment 14	0~Absolute displacement 1~Incremental displacement	-	0	Effective immediately
P10	6A	Displacement of Segment 15	-2147483648~2147483648	User's Unit	10000	Effective immediately
P10	6C	Velocity of Segment 15	0~9000	Rpm (mm/s)	300	Effective immediately
P10	6D	Acceleration time of Segment 15	0~65535	ms	10	Effective immediately
P10	6E	Deceleration time of Segment 15	0~65535	ms	10	Effective immediately
P10	6F	Waiting time of Segment 15	0~65535	ms	0	Effective immediately
P10	70	Property configuration of Segment 15	0~Absolute displacement 1~Incremental displacement	-	0	Effective immediately
P10	71	Displacement of Segment 16	-2147483648~2147483648	User's Unit	10000	Effective immediately
P10	73	Velocity of Segment 16	0~9000	Rpm (mm/s)	300	Effective immediately
P10	74	Acceleration time of Segment 17	0~65535	ms	10	Effective immediately
P10	75	Deceleration time of Segment 17	0~65535	ms	10	Effective immediately
P10	76	Waiting time of Segment 17	0~65535	ms	0	Effective immediately
P10	77	Property configuration of Segment 17	0~Absolute displacement 1~Incremental displacement	-	0	Effective immediately

P18 group motor parameters

Table of parameters for rotating motor :

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P18	00	Model of motor encoder	0~65535	-	0x1012	Effective after re-power-on
P18	02	Motor parameters of incremental encoder	0~65535	-	20001	Effective after re-power-on
P18	03	Number of encoder lines	1~83888608	p	2500	Effective after re-power-on
P18	07	Absolute encoder position offset	0~65535	p	-	Effective after re-power-on
P18	0F	Bus encoder data transmission compensation time	0~10000	0.01ms	0	Effective after re-power-on
P18	10	Current loop configuration	0~3	-	0	Effective after re-power-on
P18	11	Compensation coefficient of back EMF	0~5000	0.1%	500	Effective immediately
P18	12	D-axis coupling voltage compensation system	0~5000	0.1%	500	Effective immediately
P18	13	Q-axis coupling voltage compensation system	0~5000	0.1%	500	Effective immediately
P18	14	Current loop kp	1~20000	HZ	2000	Effective immediately
P18	15	Current loop ki	0~2000	0.01	100	Effective immediately
P18	20	Rated power	1~65535	0.01kw	-	Effective after shutdown
P18	22	Rated current	1~65535	0.01A	-	Effective after shutdown
P18	24	Maximum current	1~65535	0.01A	-	Effective after shutdown
P18	26	Rated torque	10~65535	0.01Nm	-	Effective after shutdown
P18	28	Maximum torque	10~65535	0.01Nm	-	Effective after shutdown
P18	2A	Rated velocity	10~9000	rpm	-	Effective after shutdown

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P18	2C	Maximum velocity	10~9000	rpm	-	Effective after shutdown
P18	2E	Rotational inertia	1~65535	0.01kg cm ²	-	Effective after shutdown
P18	30	Pole pairs of permanent magnet synchronous motor	1~100	-	-	Effective after shutdown
P18	31	Stator resistance	1~65535	0.001Ω	-	Effective after shutdown
P18	32	Q-axis inductance	1~65535	0.01H	-	Effective after shutdown
P18	33	D-axis inductance	1~65535	0.01H	-	Effective after shutdown
P18	34	Back EMF coefficient	1~65535	0.01mv / rpm	-	Effective after shutdown
P18	36	Torque coefficient	1~65535	0.01N/ A	-	Effective after shutdown

Parameter table of linear motor :

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P18	00	Model of motor encoder	0~65535	-	0xA000	Effective after re-power-on
P18	05	Pole distance of linear motor	1~65535	0.01mm	3200	Effective after re-power-on
P18	06	Resolution of grating ruler	1~10000	0.01um	100	Effective after re-power-on
P18	07	Absolute encoder position offset	0~65535	p	-	Effective after re-power-on
P18	09	HALL signal UVW state 1 electrical angle	0~3600	0.1 °	0	Effective after re-power-on
P18	0A	HALL signal UVW state 2 electrical angle	0~3600	0.1 °	0	Effective after re-power-on
P18	0B	HALL signal UVW state 3 electrical angle	0~3600	0.1 °	0	Effective after re-power-on
P18	0C	HALL signal UVW state 4 electrical angle	0~3600	0.1 °	0	Effective after re-power-on
P18	0D	HALL signal UVW state 5 electrical	0~3600	0.1 °	0	Effective after re-power-on

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
		angle				
P18	0E	HALL signal UVW state 6 electrical angle	0~3600	0.1 °	0	Effective after re-power-on
P18	10	Current loop configuration	0~3	-	0	Effective after re-power-on
P18	11	Compensation coefficient of back EMF	0~5000	0.1%	500	Effective immediately
P18	12	D-axis coupling voltage compensation system	0~5000	0.1%	500	Effective immediately
P18	13	Q-axis coupling voltage compensation system	0~5000	0.1%	500	Effective immediately
P18	14	Current loop kp	1~20000	HZ	2000	Effective immediately
P18	15	Current loop ki	0~2000	0.01	100	Effective immediately
P18	20	Rated power	1~65535	0.01kw	-	Effective after shutdown
P18	22	Rated current of motor (continuous current)	1~65535	0.01A	-	Effective after shutdown
P18	24	Maximum current	1~65535	0.01A	-	Effective after shutdown
P18	26	Rated torque (continuous thrust)	10~65535	0.01Nm	-	Effective after shutdown
P18	28	Maximum torque	10~65535	0.01Nm	-	Effective after shutdown
P18	2A	Rated velocity	10~9000	mm/s	-	Effective after shutdown
P18	2C	Maximum velocity	10~9000	mm/s	-	Effective after shutdown
P18	2E	Rotor mass	1~65535	g	-	Effective after shutdown
P18	30	Pole pairs of permanent magnet synchronous motor	1~100	-	1	Effective after shutdown
P18	31	Stator resistance	1~65535	0.001Ω	-	Effective after shutdown

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P18	32	Q-axis inductance	1~65535	0.01H	-	Effective after shutdown
P18	33	D-axis inductance	1~65535	0.01H	-	Effective after shutdown
P18	34	Back EMF coefficient	1~65535	0.01v/mm/s	-	Effective after shutdown
P18	36	Torque coefficient (thrust constant)	1~65535	0.01N/A	-	Effective after shutdown

Note: For rotating motor Tamagawa 23bit, P18.00 is set to 0x1012, and Tamagawa 17bit is set to 0x1010, with the 2500 line motor to be set to 0x2020 and linear motor to be set to 0xA000

P19group drive parameters

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P19	00	Drive model setting	0~65535	-	-	Effective after shutdown
P19	0A	Carrier frequency	4000~16000	HZ	8000	Effective after shutdown
P19	0B	Dead time	0~2000	0.01u	200	Effective after shutdown
P19	0C	Minimum opening time of lower bridge of bootstrap circuit	0~200	0.1u	50	Effective after shutdown
P19	0D	Relative gain of UV sampling	1~65535	-	32767	Effective after shutdown
P19	10	Measuring range of current sensor	1~999999	0.01A	-	Effective after shutdown
P19	12	FPGA phase current protection point	0~65535	0.1% current measuring range	-	Effective after shutdown
P19	14	DC bus overvoltage protection point	0~65535	v	-	Effective after shutdown
P19	15	DC bus voltage release point	0~65535	v	-	Effective after shutdown
P19	16	DC Bus voltage undervoltage point	0~65535	v	-	Effective after shutdown
P19	17	Bus voltage gain adjustment	0~2000	0.1%	1000	Effective after shutdown

Function code		Description	Setting range	Unit	Default setting	Manner of getting effective
P19	1B	Command scheduling frequency division factor	0: 4KHZ 1: 2KHZ 2:1KHZ	-	0	Effective after shutdown
P19	20	Sigma_Delta filtering time	0~3	25ns	2	Effective after shutdown
P19	21	Current sampling Sinc3 filter data extraction rate	0~3	-	1	Effective after shutdown
P19	22	TZ signal filtering time	0~31	ns	15	Effective after shutdown
P19	23	Orthogonal encoder filtering time	0~255	ns	30	Effective after shutdown
P19	24	Filtering time of linear encoder	0~255	ns	30	Effective after shutdown

U00 group status display parameters

Function code		Description	Display range	Unit
U00	00	Motor velocity	-32767~32767	rpm(*mm/s)
U00	01	Input signal monitoring DI	0~65535	-
U00	03	Output signal monitoring DO	0~65535	-
U00	05	Input command count (Use U00.34 if you need to view external commands)	-2147483647 ~2147483647	Unit of command
U00	07	Absolute position counter	-2147483647 ~2147483647	Unit of command
U00	09	Feedback pulse counter	-2147483647 ~2147483647	Unit of pulse
U00	0B	Deviation counter	-2147483647 ~2147483647	Unit of pulse
U00	0E	Average load rate	0~3000	0.1%
U00	0F	Velocity command	-9000~9000	rpm(*mm/s)
U00	10	Internal torque command	-4000~4000	0.1%
U00	11	Mechanical angle	0~3600	0.1°
U00	12	Electrical angle	0~3600	0.1°
U00	14	U current sample (rms)	-30000~30000	0.01A
U00	15	Bus voltage	0~30000	0.1v
U00	17	AI voltage value	0~20000	0.001v
U00	1A	Driver temperature	-10~200	Celsius degree
U00	1D	Total run time	0~4294967296	0.1s

Function code		Description	Display range	Unit
U00	20	Total number of input pulses	-2147483647 ~2147483647	-
U00	23	Extended data / multi-ring data of serial encoder	0~65535	-
U00	24	Feedback single turn position of serial encoder	0~8388608	p
U00	34	Actual input position command	-2147483647~ 2147483647	-
U00	36	Incremental encoder AB count	-2147483647~ 2147483647	-
U00	38	Incremental encoder Z signal count	0~65535	-
U00	3E	Function code group number with parameter exception	-	-
U00	3F	Function code intra group offset with parameter exception	-	-
U00	40	Absolute encoder fault information given by FPGA	-	-
U00	41	System state information given by FPGA	-	-
U00	42	System fault information given by FPGA	-	-
U00	43	Error information of incremental encoder	-	-
U00	44	Error information of Nikon encoder	-	-
U00	45	Error information of Tamagawa encoder	-	-
U00	43	Error information of Sankyo encoder	-	-

U01group fault and display parameters

Function code		Description	Display range	Unit
U01	00	Fault record digital setting	0~11	-
U01	01	Selected fault code	0~65535	-
U01	02	Internal fault code for the selected fault	0~65535	-
U01	03	Time stamp of the selected fault	0~4294967296	0.1s
U01	05	Velocity in case of selected fault	-37767~32767	rpm(*mm/s)
U01	06	Phase U current in case of selected fault	-37767~32767	0.01a
U01	07	Phase V current in case of selected fault	-37767~32767	0.01a
U01	08	Bus voltage in case of selected fault	0~3000	0.1v
U01	09	Input terminal status in case of selected fault	0~65535	-
U01	0A	Output terminal status in case of selected fault	0~65535	-
U01	10	Absolute encoder fault information given by FPGA in case of selected fault	0~65535	-
U01	11	System status information given by FPGA in case of selected fault	0~65535	-
U01	12	System fault information given by FPGA in case of selected fault	0~65535	-

U02group software version display parameters			
Function code	Description	Display range	Unit
U02 00	MCU Software version	-	-
U02 01	FPGA Software version	-	-
U02 02	MCU nonstandard number	-	-
U02 03	Fpga nonstandard number	-	-
U02 04	Temporary version number	-	-

Fgroup auxiliary function parameters		
Function code	Description	Setting range
F00	Panel key velocity Jog	-
F01	Inertia identification enable	-
F02	Emergency stop	0~ no operation 1~ emergency stop
F03	Initial angle identification of absolute encoder	0~ no operation 1 ~ angle identification
F04	Reset Function code	0~ no operation 1 ~ reset function code
F05	Fault reset operation	0~ no operation 1 ~ fault reset
F06	Software reset operation	0~ no operation 1 ~ software reset
F07	Absolute encoder reset operation	0~ no operation 1 ~ clear multi-ring position 2 ~ clear multi-ring position and reset fault
F08	Absolute encoder operation	0~ no operation 1~ write rom 2~ read rom
F09	AI1 automatic zero offset adjustment	0~ no operation 1 ~ AI1 automatic correction
F0A	Position Jog jogging	-
F0B	Reset fault record	0~ no operation 1 ~ reset fault record

10.2 DI/DO function

DI function parameter setting

DI function serial number	DI function description
1	Servo enable SRV_ON
2	Positive limit POT
3	Negative limit NOT
4	Home switch ORGP
5	Trigger homing enable Execute_Homing
6	Internal position mode trigger Execute_PP
7	Fault reset A_Clr
8	Operation mode switching CmdSign
9	Emergency stop signal E_Stop
10	Pause signal HaltOption
11	Operation mode switching 1Mode_Sel1
12	Operation mode switching 2Mode_Sel2 where (1Mode_Sel1=0 and Mode_Sel2=0) is position mode (1Mode_Sel1=1 and Mode_Sel2=0) is velocity mode (1Mode_Sel1=0 and Mode_Sel2=1) is torque mode (1Mode_Sel1=1 and Mode_Sel2=1) is position mode
13	Positive jogging JogCmdP
14	Negative jogging JogCmdN
15	Zero position fixing ZeroLock
16	Gain switching Gain
17	Electronic gear ratio switching GearSw
18	Pulse prohibition INH
19	Pulse deviation clearing CL
20	Probe release probeEnable

DO function parameter setting

DO function serial number	DO functional description
1	Servo ready status output SRdy
2	Servo enable state output Son
3	Positioning OK output INP
4	Warning output signal Warn
5	Fault output signal Alm
6	Brake signal Blk
7	Homing OK output HomeOK
13	Zero velocity signal output SZero
14	velocity consistent signal VIn
15	velocity reach output VRot
16	Torque command reach signal ToqReach
17	Probe locking ProbeLock

Chapter 11 Commissioning of Linear Motor

11.1 Procedure for commissioning of linear motor




Figure 11-1 Flow Chart for Commissioning of Linear Motor

11.2 Parameter setting of linear motor

1. Set the parameters of linear motor:

P18.00 Linear motor code	Setting range	Unit	Factory default	Related mode		
	1~65535	-	0xA000	P	S	T

Notes: The parameter of linear motor must be set to 0xA000

P18.05 Pole distance of linear motor	Setting range	Unit	Factory default	Related mode		
	1~65535	0.01mm	32.00	P	S	T

Notes:

Set the distance length of N-N poles, for example, the pole distance is 25mm, with P18.05 to be set to 25.00.

P18.06 Resolution of grating ruler	Setting range	Unit	Factory default	Related mode		
	1~10000	0.01um	10	P	S	T

Notes:

Set the Unit of grating ruler resolution to 0.01u, i.e. the distance traveled by a pulse (after quadruple frequency) fed back by the grating ruler.

If the resolution of the grating ruler is 5um, set P18.06 to 5.00.

P18.22 Rated current of motor (continuous current)	Setting range	Unit	Factory default	Related mode		
	1~10000	0.01A	10	P	S	T

Notes:

Set the rated current value of the motor, Unit0.01A

If the rated current of the motor is 3.4A, set P18.2 to 3.40.

P18.24 Maximum current of motor	Setting range	Unit	Factory default	Related mode		
	1~10000	0.01A	10	P	S	T

Notes:

Set the maximum current value of the motor, Unit0.01A

If the maximum current of the motor is 12.3A, set P18.24 to 12.30.

P18.26 Rated torque (continuous thrust)	Setting range	Unit	Factory default	Related mode		
	1~65535	0.01N	10	P	S	T

Notes:

Set the rated torque (continuous thrust value) of the motor, for example, the continuous thrust of the linear motor is 106N,

set P18.26 to 106.00

P18.2A Rated velocity of motor	Setting range	Unit	Factory default	Related mode		
	10~9000	mm/s	3000	0P	S	T

Notes:

The default is 3000 mm/s.

P18.2C Maximum velocity of motor	Setting range	Unit	Factory default	Related mode		
	10~9000	mm/s	5000	P	S	T

Notes:

The default is 5000mm/s

P18.2E Rotor mass	Setting range	Unit	Factory default	Related mode		
	1~65535	g	10	P	S	T

Notes:
Set the unit of rotor mass to g, for example, the mass of motor rotor is 1.3kg.
Set P18.2E to 1300

P18.30 Number of pole-pairs	Setting range	Unit	Factory default	Related mode		
	1~65535	-	-	P	S	T

Notes: The linear motor can be directly set to 1

P18.31 Resistance value of stator resistor	Setting range	Unit	Factory default	Related mode		
	1~65535	0.001Ω	10	P	S	T

Notes:
Set the resistance value of the resistor of the motor stator, for example, if the motor linear resistance is 2.6Ω, the stator resistance is 2.6/2=1.3Ω
Set P18.31 to 1.300

P18.32 Lq inductance value of stator	Setting range	Unit	Factory default	Related mode		
	1~65535	0.01mh	10	P	S	T

Notes:
Set the inductance value of stator Lq , for example, if the linear inductance value is 8.6mh the inductance of stator is 8.6/2 = 4.3mH.
Set P18.32 to 4.30

P18.33 Ld inductance value of stator	Setting range	Unit	Factory default	Related mode		
	1~65535	0.01mh	10	P	S	T

Notes:
Set the Ld inductance value of the stator, for example, if the linear inductance is 8.6mh, the stator inductance is 8.6/2 = 4.3mH.
Set P18.32 to 4.30 (it will be OK to be set to that similar to P18.32)

P18.34 Back EMF coefficient	Setting range	Unit	Factory default	Related mode		
	1~65535	0.01v/ mm/s	10	P	S	T

Notes:
Set the back EMF coefficient of the motor, for example, if the back EMF of the motor is 27.6 V/m/s,

Set P18.34 to 27.60

P18.36 Torque coefficient (thrust constant)	Setting range	Unit	Factory default	Related mode		
	1~65535	0.01N/A	10	P	S	T

Notes:

Set the thrust constant of the motor, for example, if the thrust constant of the motor is 22.4N/A
Set to 22.40

Effective after re-power-on at the end of setting,

11.3 Check the signal feedback of linear motor

Check the feedback pulse count of U00.09 grating ruler, and push the motor for a distance to observe whether U00.09 increases (or decreases) the corresponding pulse number. For example, if the resolution of grating ruler P18.06 is 1.00u, then U00.09 should increase 100000 pulses after pushing the motor positively for 10cm, and decrease 100000 pulses after pushing the motor negatively for 10cm. If the grating ruler Z signal is used, you can check whether the Z signal count is normal through U00.38. Each time the Z signal is encountered, the U00.08 count increases by 1.

If the hall signal is used, the status of the hall signal can be displayed through function code U00.39

U00.39	Hall_W	Hall_V	Hall_U
0	0	0	0
1	0	0	1
2	0	1	0
3	0	1	1
4	1	0	0
5	1	0	1
6	1	1	0
7	1	1	0

11.4 Linear angle identification

When F03 = 1 is used for angle identification, the angle identification method shall be selected according to the actual situation:

P0A.0B Selection of angle identification mode	Setting range	Unit	Factory default	Related mode		
	0-4	-	0	P	S	T


Notes:

- 0: Pre-positioning identification mode: In the identification process, the motor can move a maximum distance between poles.
- 1: Specified electric angle identification mode: In the identification process, the motor runs to the electric angle specified by the user (P0A.0E).
- 2: jogging identification mode 1: This mode can be used after the gain motor parameters are matched, and the moving distance is very small.
- 3: jogging identification mode 2: small moving distance, uncoupled gain. (Recommended).
- 4: Hall identification mode: learn the hall signal position. After the motor is installed, it only needs to be identified once, and then it does not need to identify the angle.

During hall identification, it is necessary to set P0a.0b to 4 and use F03 = 1 for angle identification. After identification, the angle corresponding to Hall signal is saved in P18.09 ~ P18.0E. Check the angle interval of the result about 60 ° and roughly judge whether the identification result is accurate. If the alarm AI.01.5 (phase sequence error) occurs during angle identification, please replace phase sequence U and V.

11.5 Linear commissioning

For example, select a lower velocity for operation 50mm/s.



During the trial operation, in case of runaway AI.05.5, stalling AI.02.A and motor overload AI.02.9, the electric angle may be wrong.

It is necessary to confirm whether P18.05, P18.06 and P18.30 are set correctly.

Other gain commissioning and pulse mode can be set according to the requirements in the user instruction .